

Pcb-20050127

un système interactif de
conception de cartes de circuits imprimés
pour X11

harry eaton

Table of Contents

Copying	1
Historique	2
1 Survol	4
2 Introduction	5
2.1 Symboles	5
2.2 Vias	5
2.3 éléments	5
2.4 Layers	7
2.5 Lines	8
2.6 Arcs	9
2.7 Polygons	9
2.8 Text	10
2.9 Nets	10
3 Démarrage	12
3.1 La fenêtre d'Application	12
3.1.1 Menus	12
3.1.2 La ligne de statut et le champ d'entr�e	15
3.1.3 The Panner Control	16
3.1.4 The Layer Controls	17
3.1.5 The Tool Selectors	17
3.1.6 Layout Area	19
3.2 Log Window	20
3.3 Library Window	20
3.4 Netlist Window	20
3.5 Drawing and Removing Basic Objects	21
3.5.1 Lines	22
3.5.2 Arcs	22
3.5.3 Polygons and Rectangles	22
3.5.4 Text	23
3.5.5 Vias	23
3.5.6 Elements	24
3.5.7 Pastebuffer	25
3.6 Moving and Copying	26
3.7 Loading and Saving	26
3.8 Printing	26
3.9 Connection Lists	28
3.10 Arrow Tool	28
3.11 Rats Nest	29

3.12	Design Rule Checking	30
3.13	Trace Optimizer	31
3.14	Searching for elements	32
3.15	Measuring distances	32
3.16	Vendor Drill Mapping	32
4	Commandes Utilisateur	34
5	Command-Line Options	36
5.1	Options	36
5.2	Special Options	38
6	X11 Interface	39
6.1	Non-Standard X11 Application Resources	39
6.2	Actions	45
6.3	Default Translations	55
7	File Formats	56
7.1	Basic Types	56
7.2	Layout File Format	57
7.3	Element File Format	59
7.4	Font File Format	61
7.5	Netlist File Format	61
7.6	Library Contents File Format	62
7.7	Library File Format	62
8	Library Creation	64
8.1	Old Style (m4) Libraries	64
8.1.1	Overview of Oldlib Operation	64
8.1.2	The Library Scripts	65
8.1.2.1	Scripts Used During Compilation	65
8.1.2.2	Scripts Used by PCB at Runtime	66
8.1.3	Creating an Oldlib Footprint	67
8.1.4	Troubleshooting Old Style Libraries	69
8.2	New Style Libraries	70
8.2.1	Creating Newlib Footprints	70
8.2.2	Modifying Newlib Footprints	71

9	Capture de schémas pour PCB	72
9.1	gEDA	72
9.1.1	Configurer les Répertoires de Projets	72
9.1.2	Configurer les fichiers de configuration de gEDA	73
9.1.3	Configurer les fichiers de configuration de gsch2pcb	73
9.1.4	Capture de schémas en utilisant gschem	73
9.1.5	Créer toutes les empreintes de PCB uniques	74
9.1.6	Générer un dessin initial de PCB en utilisant gsch2pcb	74
9.1.7	Carte de circuit imprimé	74
9.2	Annotation directe des changements de schémas	74
9.2.1	Générer les fichiers Photoplot (RS-274-X)	75
9.3	xcircuit	75
Appendix A	Installation and Troubleshooting	76
.....		
A.1	Compiling and Installing	76
A.1.1	Quick Start	76
A.1.2	Running the configure Script	76
A.2	Troubleshooting	76
A.2.1	HP Series 700 and 800	77
A.2.2	Sun SPARC architecture	77
A.2.3	Silicon Graphics	77
A.2.4	DEC Alpha	77
A.2.5	SCO Unix	77
A.2.6	Linux	77
A.2.7	FreeBSD and NetBSD	78
A.2.8	Problems related to X11	78
A.2.9	Problems related to TeX	78
Appendix B	Customizing the Menus	79
B.1	Resource Syntax	79
B.2	Menu Definitions	80
B.3	Menu Files and Defaults	81
Appendix C	Element Search/Regular Expressions	82
C.1	Element Search/Regular Expressions	82
Appendix D	Standard Drill Size Tables	83
D.1	American Standard Wire Size Drills	83
D.2	American Standard Letter Size Drills	83
D.3	Fractional Inch Size Drills	83
D.4	Metric Drills	83
Index of Resources		85

Index of Actions, Commands and Options	87
Index of Concepts	89

Copying

Copyright © 1994,1995,1996,1997 Thomas Nau

Copyright © 1998,1999,2000,2001,2002 harry eaton

Traduit par Iznogood de la Iznogood-Factory.org

This program is free software; you may redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the **GNU General Public License** for more details.

Historique

Pcb est un outil pratique pour créer des cartes de circuits imprimés.

Pcb was first written by Thomas Nau for an Atari ST in 1990 and ported to UNIX and X11 in 1994. It was not intended as a professional layout system, but as a tool which supports people who do some home-developing of hardware.

The second release 1.2 included menus for the first time. This made Pcb easier to use and thus a more important tool.

Release 1.3 introduced undo for highly-destructive commands, more straightforward action handling and scalable fonts. Layer-groups were introduced to group signal-layers together.

Release 1.4 provided support for add-on device drivers. Two layers (the solder and the component side) were added to support SMD elements. The handling of libraries was also improved in 1.4.1. Support for additional devices like GERBER plotters started in 1.4.4. The undo feature was expanded and the redo-feature added in 1.4.5.

harry eaton took over pcb development beginning with Release 1.5, although he contributed some code beginning with Release 1.4.3

Release 1.5 provides support for rats-nest generation from simple net lists. It also allows for automatic clearances around pins that pierce a polygon. A variety of other enhancements including a Gerber RS-274-X driver and NC drill file generation have also been added.

Release 1.6 provides automatic screen updates of changed regions. This should eliminate most of the need for the redraw (*R* key). Also some changes to what order items under the cursor are selected were made for better consistency - it is no longer possible to accidentally move a line or line point that is completely obscured by a polygon laying over top of it. Larger objects on the upper most layers can be selected ahead of smaller objects on lower layers. These changes make operations more intuitive. A new mode of line creation was added that creates two line on 45 degree angles with a single click. The actual outline of the prospective line(s) are now shown during line creation. An arc creation mode was added. Drawn arcs are quarter circles and can be useful for high frequency controlled impedance lines. (You can have eighth circle arc if the source is compiled with -DARC45, but be aware that the ends of such arcs can never intersect a grid point). Two new flags for pins and vias were created - one indicates that the pin or via is purely a drill hole and has no copper annulus. You can only toggle this flag for vias - for elements, it must be an integral part of the element definition. The other flag controls whether the pad will be round or octagonal. There is also now a feature for converting the contents of a buffer into an element.

Release 1.6.1 added the ability to make groups of action commands bound to a single X11 event to be undone by a single undo. Also a simple design rule checker was added - it checks for minimum spacing and overlap rules. Plus many fixes for bugs introduced with the many changes of 1.6

Release 1.7 added support for routing tracks through polygons without touching them. It also added support for unplated drill files, and drawing directly on the silk layer. A Netlist window for easily working with netlist was also added.

La version 2.0 ajoute un routeur automatique, un nouveau mécanisme plus simple pour les bibliothèques, un support pour la création (et l'édition) des éléments beaucoup

amélioré, une couche de masque de soudure visible (et éditable), le snap vers les broches et les pastilles, les entrées de netlist en dessinant les liaisons, les fichiers (et bibliothèques) d'éléments peuvent contenir des sous-couches, des grilles métriques, une interface utilisateur améliorée, un système de construction basé sur GNU autoconf/automake et des tonnes d'autres améliorations.

Special thanks goes to:

Thomas Nau (who started the project and wrote the early versions).

C. Scott Ananian (who wrote the auto-router code).

Bernhard Daeubler (Bernhard.Daeubler@physik.uni-ulm.de)

Harald Daeubler (Harald.Daeubler@physik.uni-ulm.de)

DJ Delorie (djdelorie@users.sourceforge.net)

Larry Doolittle (ldoolitt@recycle.lbl.gov)

Dan McMahill (danmc@users.sourceforge.net)

Roland Merk (merk@faw.uni-ulm.de)

Erland Unruh (Erland.Unruh@malmo.trab.se)

Albert John FitzPatrick III (ajf_nylorac@acm.org)

Boerge Strand (borges@ifi.uio.no)

Andre M. Hedrick (hedrick@Astro.Dyer.Vanderbilt.Edu)

who provided all sorts of help including porting Pcb to several operating systems and platforms, bug fixes, library enhancement, user interface suggestions and more. In addition to these people, many others donated time for bug-fixing and other important work. Some of them can be identified in the source code files. Thanks to all of them. If you feel left out of this list, I apologize; please send me an e-mail and I'll try to correct the omission.

1 Survol

Pcb est un éditeur de carte de circuits imprimés pour le système de gestion de fenêtres X11. Pcb inclut plusieurs fonctionnalités professionnelles telles que:

- Jusqu'à 8 couches de cuivre
- Sortie RS-274-X (Gerber)
- Sortie de perçage NC (NC Drill)
- Centrage des sorties de données (X-Y)
- Sortie Postscript et Postscript Encapsulé
- Autorouteur
- Optimiseur de pistes
- Liaisons
- Design Rule Checker (DRC)
- Vérification de connectivité
- Pcb est Free Software
- Il peut interagir avec des outils de capture de schémas libre tels que gEDA et xcircuit

2 Introduction

Chaque schéma consiste en plusieurs objets, en grande partie indépendants. Ce chapitre donne un survol des types d'objets et leurs relations les uns avec les autres. Pour une description complète sur la manière d'utiliser `Pcb`, allez à Chapter 3 [Démarrage], page 12. Le schéma est généré à l'écran sur une grille qui peut avoir son origine à l'endroit désiré. La coordonnée X augmente vers la droite, Y augmente en descendant vers le bas. Toutes les distances et les tailles de `Pcb` sont mesurées en mils (0.001 inch). Une unité sur l'affichage des coordonnées forme une distance de un mil sur la carte. La grille peut être mise sur une valeur métrique mais ne sera correcte qu'à +/- 0.01 mil près car `Pcb` stocke toutes les dimensions sous forme d'entiers, multiples 1/100 de mil ou 0.00001 inch.

Les sections dans ce chapitre sont triées dans l'ordre d'apparence des objets dans un fichier schéma.

2.1 Symboles

L'objet principal est le dessin lui-même. Il utilise un jeu de symboles qui réside dans le premier niveau logique. Chaque symbole est uniquement identifié par un code ASCII à sept bits. Tous les objets du schéma partagent le même jeu de symboles. Ces symboles sont utilisés pour former les objets texte sur la couche impression et sur les couches cuivre. Les symboles indéfinis sont dessinés comme des rectangles pleins.

Chaque fichier de police est pré-traité par une commande définie par l'utilisateur lorsqu'il est chargé. Pour les détails, voyez '`fontCommand`', Section 6.1 [Ressources], page 39.

2.2 Vias

Les vias fournissent connectivité traversante entre les couches. Alors que les vias ressemblent beaucoup aux éléments de broches, n'utilisez pas les vias pour ajouter des éléments au circuit, même si cela semble plus facile que de créer un nouvel élément. Le masque de soudure par défaut couvrira les vias, vous ne pourrez donc pas les souder. Vous pouvez bien sr le modifier pour que les masques de soudure aient des ajourages mais ce n'est pas le cas par défaut. Les vias sont aussi utiles pour définir des points de perçage arbitraires tels que ceux utilisés pour monter une carte. Les vias utilisés de cette manière utilisent un jeu de drapeaux spéciaux de telle manière qu'ils n'aient pas d'anneau de cuivre et apparaissent dans le fichier de perçage `unplated`. La touche `Ctrl-H` au-dessus d'un via change entre un pur trou de montage et un via régulier. Vous pouvez assigner un nom à un via, ce qui est utile pendant la création d'une nouvelle définition d'élément. Chaque via existe sur toutes les couches de cuivre. (*i.e.* les vias aveugles et bouchés ne sont pas supportés)

2.3 éléments

Les éléments représentent les composants sur la carte. Les éléments sont chargés depuis les fichiers codés en ASCII d'une manière identique au circuit lui-même ou depuis la fenêtre de sélection des bibliothèques. Un élément est composé de lignes et d'arcs sur la couche impression (utilisé pour définir le contour du boîtier), de broches (ou de pastilles pour les CMS) et trois labels qui définissent la description, le nom de couche de l'élément (qui apparaît aussi sur la couche d'impression) et sa valeur. Vous pouvez choisir quels nom sont affichés sur l'écran avec le menu **Ecran**; néanmoins, l'impression en sortie montrera toujours

le nom du schéma. Les broches élément sont contenues sur le premier niveau logique et résident donc sur toutes les couches mais les pastilles des éléments montés en surface sont seulement sur les couches composant ou soudure. Un élément peut avoir un mélange de broches, pastilles (sur un ou deux côtés) et des trous de montage.

Une marque est utilisée pour placer un élément en fonction de la position du curseur pendant le coller. La marque sera sur le point de grille lorsque l'élément est positionné. La marque est dessinée comme sous la forme d'un diamant mais est seulement visible lorsque les *deux* couches `impression` et `broches/pastilles` sont visibles. Toutes les parties d'un élément sont traités comme une unité, excepté pour le nom. Il n'est pas possible d'effacer une broche seule ou déplacer seulement une partie de l'élément sur le schéma. Vous pouvez ajuster la taille des pièces d'un élément séparément mais le fait est habituellement une mauvaise idée. Vous pouvez déplacer/pivoter le nom d'élément indépendamment de l'élément auquel il appartient. Lorsque vous bougez un nom d'élément, une ligne est dessinée depuis le curseur vers la marque de l'élément de telle manière qu'il soit facile d'indiquer à quel élément appartient le nom.

Chaque broche et pastille possède deux chaînes d'identificateur, l'une est le "nom" qui est une description fonctionnelle de la broche (*i.e.* "clock in") et l'autre est le "numéro" de la broche qui est utilisé pour l'identifier dans une netlist. Le "numéro" est habituellement un entier mais il peut être n'importe quelle chaîne. Vous pouvez éditer le "nom" de chaque broche d'un élément mais le "numéro" est embarqué dans la définition d'élément et est déterminé lorsque le nouvel élément est d'abord créé. Les pastilles sont similaires aux lignes sur une couche mais elles doivent être orientées soit verticalement soit horizontalement. Les pastilles peuvent avoir des terminaisons soit arrondies soit carrées. Les broches peuvent être rondes, carrées ou octogonales.

Les éléments sont portés par plusieurs couches spéciales: `impression`, `broche/pastille` et `côté éloigné`. La couche `impression` montre le contour du boîtier et contient aussi le texte de légende et les noms d'éléments. La couche `broche/pastilles` est utilisée pour commuter l'affichage des broches et des pastilles de l'élément. La couche `côté opposé` contrôle la visibilité des objets (`impression` et `pastilles`) qui sont sur le côté opposé (*i.e.* pas visible actuellement) de la carte.

Le style "oldlib" des bibliothèques distribuées avec `Pcb` dépend du processeur de macros `M4`. `M4` est typiquement installé sous le nom de `m4` dans la plupart des systèmes d'exploitations unix. Il est recommandé d'utiliser la version GNU de `M4` pour éviter les limitations trouvées dans les implémentations de fabricants. Voyez la page de man `m4` sur votre système pour plus d'information. Chaque fichier élément est pré-traité par une commande définie par l'utilisateur lorsque le fichier est lu. Pour les détails, voyez '`elementCommand`', Section 6.1 [Ressources], page 39. `m4`, la valeur par défaut de '`elementCommand`', vous permet de créer des bibliothèques pour les définitions de paquet qui sont partagées par tous les éléments. Les bibliothèques d'anciens éléments distribuées avec `Pcb` attendent `m4` ou un équivalent `elementCommand`. Le système des nouvelles bibliothèques possède chaque élément stocké dans un seul fichier, il n'y a donc pas de besoin d'apprendre `m4` pour ajouter des bibliothèques.

`Pcb` peut créer une liste de toutes les connexions depuis un (ou tous) élément vers les autres ou une liste des broches npn connectées. Il peut aussi vérifier les connexions d'un schéma dans un fichier netlist. Le '`layout-name`' de l'élément est le nom utilisé pour identifier l'élément dans un fichier netlist (voyez Section 7.5 [Fichier Netlist], page 61).

Les vieilles bibliothèques ou les très vieux fichiers de circuits (pre-1.6) peuvent avoir des numrotations de broches incorrectes car il n’y avait pas de concept de numéro de broche lorsqu’ils ont été créés. Pcb utilise l’ordre d’apparence des définitions de broches dans le circuit ou le fichier bibliothèque s’il utilise l’ancien format mais il n’existe pas de garantie qu’il sera correct pour ces vieux objets.

Faites attention au fait que les composants des anciennes bibliothèques peuvent encore avoir une numrotation de broche mal implémentée. Tous les composants DIL (Brochage Dual-Inline) sont corrects et la plupart des autres le sont aussi mais vous devriez vérifier la numrotation des broches de tout composant non-DIL avant d’utiliser un composant de la vieille bibliothèque. (utilisez ‘rapport d’objet gnr’ dans le menu **Info** pour voir ce que pense Pcb du numéro de broche) Tous les noms de bibliothèques commencent avec un ~, vous pouvez donc facilement les identifier. Les vieilles bibliothèques *peuvent* aussi contenir d’autres sortes d’erreurs, incluant des espacements de broche incorrects, des chevauchements de zones de soudure sur la couche d’impression, etc. **Contrôlez avec attention tout élément dans la vieille bibliothèque avant de l’utiliser!** Alors que la nouvelle bibliothèque est créée, la vieille bibliothèque sera utilisée pour au moins enlever tous les éléments avec erreurs mais cela prendra du temps.

Maintenant, vous pouvez réaliser vos propres définitions d’éléments graphiquement. Dessinez simplement les vias pour les broches, les lignes sur les couches de soudure et/ou de composant pour les pastilles des composants de montage en surface (ils peuvent être soit horizontaux soit verticaux), les lignes et les arcs pour les contours sur la couche d’impression. Vous devriez nommer (touche *N*) chaque via et piste de cuivre avec le numéro de la broche. Une fois que vous êtes satisfaits avec la géométrie, sélectionnez tout ce qui fait partie de l’élément et choisissez ‘conversion de la sélection en élément’ depuis le menu **Sélection**. Plus tard, vous pourrez rendre les broches (ou pastilles) carrées si vous voulez et donner l’élément divers noms. Vous pouvez aussi donner aux broches et pastilles leur nom fonctionnel. Notez que l’élément marqué correspond à la position à laquelle vous cliquez après avoir choisi conversion dans le menu, vous devez donc décider où sera la marque et vous assurez qu’elle tombera sur un point de la grille avant de faire la conversion. Si les vias/lignes ne sont pas nommés, alors la numrotation de broche correspond à l’ordre dans lequel elles sont placées.

When you create a new element, remember that silkscreen lines should *never* overlap the copper part of the pins or pads, as this can interfere with soldering. The silkscreen should identify the maximum extent of the element package so it is easy to see how close elements can be placed together.

If you want to make an element similar to an existing one, you can break an element into constituent pieces from the **Buffer** menu. Paste the pieces to the layout, make the necessary changes, then convert it back into an element. If the pin numbers haven’t changed, there is no need to name each via/line as they are pre-named when the element was broken apart. When you create a new element, you can save it to a file in order to have easy access to it the next time you run Pcb.

2.4 Layers

Every layout consists of several layers that can be used independently or treated as a group. Layer groups can be used to logically separate (and color-code) different traces (*e.g.* power and signal); however, all layers within a group reside on the same physical copper layer of

a board, so using different layers within the same group won't provide electrical separation where they touch or overlap. For details, see 'layerGroups', Section 6.1 [Resources], page 39. Each layer is drawn in a color defined in the resource file and identified by a name that you can change (for details see 'layerColor', Section 6.1 [Resources], page 39.) Layers are really just containers for line, arc, polygon, and text objects. The component and solder layers contain SMD elements as well, but the file structure doesn't reflect that fact directly.

Each layer group represents a physical layer on the printed circuit board. If you want to make a four layer board, you'll need to have at least four layer groups. Connections between layer groups are established only through element pins and vias. The relationship between a specific layer and the board itself is configurable from the 'Edit layer groups' option in the **Settings** menu. The layer groups corresponding to the physical layers: *component-side* and *solder-side* are always defined and you must map at least one logical layer to each, even if you plan to make a single-sided board. You are not obligated to put tracks on either of them. Surface mount elements always reside on either the component-side or the solder-side layer group. When you paste an element from the buffer, it will go onto whichever side of the board you are viewing. You can swap which side of the board you are viewing by pressing the *Tab* key, or by selecting 'view solder side' from the **Screen** menu. The layer groups just have a name or number associated with them - where they are sandwiched in the board is left for you to tell the manufacturer.

The silkscreen layer is special because there are actually two silkscreen layers, one for the top (component) and one for the bottom (solder) side of the board. Which silk layer you draw on is determined by the side of the board that you are viewing. If you are viewing the component side, then drawing on the silk layer draws to the component-side silk layer.

The netlist layer is another special layer. It shows rat's-nest lines (*i.e.* guides that show how the netlist expects the element to interconnect). If you make this the active layer, you can use the Line tool to add entries into the netlist, or to delete connections from the netlist window. Except for these two purposes, you should not make the netlist layer the active layer. Usually there is no need to do this because a separate schematic package should be used to create the netlist. **Pcb** can automatically draw all of the rats from the netlist. In some cases you may want to make a small change without going to the trouble of modifying the schematic, which is why this facility is provided.

2.5 Lines

Lines are used to draw tracks on the pc board. When in the line mode, each *Btn1* press establishes one end of a line. Once the second point is defined, the line is drawn and a new line started where the first one ended. You can abandon the new starting point in favor of another by pressing *Ctrl-Btn1*, or *Btn3*, but don't use *Btn2*. The undo function (*U* key or 'undo last operation' from the **Edit** menu) will take you back point by point if you use it while in the line mode. If you drag the pointer out of the Layout area while drawing a line, the display will auto-scroll (assuming sufficient zoom for scrolling). To stop auto-scroll, simply pass the pointer over the panner control.

New lines can be restricted to 45 degree angles if desired. You can toggle this restriction on and off while creating lines by pressing the *period* key. If the 45 degree restriction is turned on, then the / (forward slash) key can be used to cycle through three different

modes of 45 degree line creation. One mode just creates a single line forced to the nearest 45 degree vector. The next mode creates two lines from the start to end points such that the first line leaves the start point at a 90 degree vector, and the second line enters the end point on a 45 degree vector. The last mode creates two lines such that the first line leaves the start point on a 45 degree vector and arrives at the end point on a 90 degree vector. You can temporarily swap between the last two modes by holding the *Shift* key down.

It is simple to edit a line object by breaking it into pieces (insert point mode), moving an end point or the whole line (*Arrow tool*), or changing the layer it resides on (*M* key moves the line under the pointer to the active layer). In the case when two line segments meet at exactly the same point you can delete the intermediate point, otherwise the delete tool removes an entire line. Feel free to experiment since *Pcb* will allow you to undo and redo anything that materially affects your work. If you switch active layers in the midst of placing lines a via will automatically be placed, when necessary, in order to continue the connection.

If you draw a line inside a polygon, it will either plow through the polygon creating a clearance, or touch the polygon. This behavior is selectable in the **Settings** menu for new lines. To change the behavior of an existing line, hit the *J* key with the cross hair over the line. You can increase the size of the clearance by 2 mils on each edge with the with the *K* key. *Shift-K* will decrease the clearance by 2 mils. The increment may be changed from 2 mils through the application resource file. The clearance can be also increased, decreased and set by the *ChangeClearSize* action.

Lines do not need to intersect the center of a pin, pad, via, or other line for *Pcb* to understand that they make electrical connection. If the connection is too tenuous, running the design rule checker will report that the connection may break if the line width shrinks slightly.

2.6 Arcs

Pcb can handle arcs of any angular extent, but when you create an arc with the Arc tool, it will be a quarter circle (this means they always bend a right angle). Arcs are very similar to lines otherwise. They are created on the active layer and have the same thickness that new lines will have. The various clicks for creating lines work pretty much the same way for creating arcs. In order to make the arc curve in the desired direction, drag the mouse along the tangent line from the starting position towards the end position. If the grid is too coarse, it may not be possible to distinguish whether you've moved over then up, or up then over, so if you can't seem to make the arc go in the direction you want, try pressing the *Shift* key while drawing the arc. Decreasing the grid spacing may also help. Alternatively you can draw the wrong arc, then rotate and move it where you want. Like the Line tool, after an arc is drawn a new starting point is established at the end point.

Whenever a starting point is established by either the Line or Arc tools it will be retained if you switch directly between the tools (e.g. *F2* key for Lines, *F8* key for Arcs. Arcs can either touch or clear polygons just like lines do. Of course connection searches, undo and all the other features you'd expect work with arcs too.

2.7 Polygons

Sometimes it's useful to fill large areas with solid copper. The way to do this is with polygons. Polygons can be created in either the polygon mode or the rectangle mode. In the polygon mode, you'll have to define each corner of the polygon with a mouse click (*Btn1*). When the last point is clicked exactly on top of the starting point, the polygon is finished. Since this can be hard to do, the *Shift-P* key will enter the final point for you, closing the polygon. If the 45 degree angle restriction is turned on and you try to close the polygon when it is not possible, you'll get a warning instead. If you haven't finished entering a polygon, but want to undo one (or more) of the points that you've already defined, use the undo command (*U* key).

With the rectangle tool, defining the two diagonally opposite corners is sufficient, but of course the resulting polygon is a rectangle. Like lines, a polygon can be edited by deleting, inserting and moving the points that define it. Pins and vias *always* clear through polygons without touching them when first positioned. You must add a thermal with the thermal tool in order to connect pins and vias to polygons. Thermals can be added and removed by clicking *Btn1* with the thermal tool over the pin or via. The thermal tool always places a thermal to polygons on the active layer, so if the tool doesn't seem to work, it's probably because the polygon you want to touch is not on the active layer.

Pcb is capable of handling complex polygons, but using a number of simpler ones improves performance of the connection tracing code. You also must be careful not to create polygons that touch or overlap themselves. The fabricated board may not look the way you expect if you violate this principle. It is always ok to have two (or more) polygons touch or overlap each other, but not for points within the same polygon to do so.

The great advantage to this new polygon behavior is that simple or complex ground and/or power planes can be easily made with polygons and seen on the screen. If you don't want this auto-clearance behavior, or you load a layout created by an early version of Pcb, the old behavior (shorts to all piercing pins and vias) is available. A 'ChangeSize' operation (*S* key) toggles a polygon between the new and old polygon/pin behavior.

2.8 Text

Text objects should be used to label a layout or to put additional information on the board. Elements have their 'layout-name' labels on the silk-screen layer. If you are making a board without a silkscreen, you can use copper text to label the elements, but you have to do this manually.

Text is always horizontal when first created, but the rotate mode can align it along 0, 90, 180 and 270 degree angles. Text on the far side of the board will automatically appear mirror-imaged.

Warning: TEXT OBJECTS ON A COPPER LAYER CREATE COPPER LINES BUT THEY ARE NOT SCANNED FOR CONNECTIONS OR TESTED FOR CREATING SHORTS VS. THE NETLIST. NEITHER ARE TEXT OBJECTS TESTED AGAINST ANY DESIGN RULES.

2.9 Nets

Layout files also contain the netlist that describes how the elements are supposed to be interconnected. This list of connections can be loaded from a netlist file (see Section 7.5 [Fichier Netlist], page 61), or entered by drawing rat-lines as described previously. Each net has a name and routing style associated with it. The net contains a list of all element *layout-name* names and pin *numbers* that should be connected to the net. Loading a netlist file will replace all existing nets with the ones from the file. The *Netlist* window provides an easy way to browse through the net list. You can display the rat's-nest by selecting 'optimize rats-nest' from the **Connects** menu. If you move or rotate elements, the rat's-nest will automatically follow the movements, but they won't necessarily show the shortest paths until you optimize them again.

3 Démarrage

L'objectif de ce chapitre est de vous donner suffisamment d'informations pour apprendre comment fonctionne `Pcb` et comment développer vos circuits pour faire la meilleure utilisation des fonctionnalités de `Pcb`. Toutes les traductions d'événements (*i.e.* les boutons et les touches que vous pressez) réfèrent au fichier ressource des applications par défaut fourni avec `Pcb`. Il n'y a aucune raison de faire des changements à moins que que votre gestionnaire de fenêtre n'utilise aussi certains des événements des boutons; néanmoins, si vous *voulez* personnaliser le comportement de `Pcb` alors faire des changements dans le fichier ressources est habituellement la meilleure manière de le faire.

Faites une impression de ce chapitre et des *Commandes Utilisateur*, si vous ne l'avez pas encore fait et suivez les exemples.

Démarrez `Pcb` (la commande réelle utilise les minuscules) sans options supplémentaires. Si vous avez le message d'erreur:

```
can't find default font-symbol-file 'default_font'
```

alors le chemin de recherche des polices ou le nom de fichier dans le fichier ressource des applications est mauvais. Assurez-vous que votre programme `m4` supporte les chemins de recherche. Si ce n'est pas le cas, recherchez `GNU m4`. Pour les autres messages, voyez Section A.2 [problems], page 76. Un autre démarrage rapide est fourni par `pcbtest.sh` dans le répertoire 'src'. Si quelques fonctionnalités semblent ne pas marcher, tentez de lancer `pcbtest.sh`, si cela fonctionne alors `Pcb` n'a pas été installé correctement.

3.1 La fenêtre d'Application

La fenêtre principale consiste en six zones: le menu au sommet, le contrôle des couches en haut à gauche, les boutons d'outils sous les contrôles de couches, la zone de Dessin à droite et la ligne de statut en bas de la fenêtre.

3.1.1 Menus

Les menus sont situés au sommet de la zone de Dessin. La plupart, mais pas toutes, des fonctions sont aussi disponibles depuis le clavier. De même quelque fonctions ne ne seulement réalisables que par les entrées clavier ou de commande. Quelque entrées de menu tel que 'center layout' dans le menu **Screen** nécessite une certaine position de curseur. Dans ce cas un message au prompt apparaîtra au bas de l'écran avec des mots semblables à ce qui suit:

```
move pointer to the appropriate screen position and press a button
```

Tout bouton de souris fera l'affaire, puisque toute touche excepté les touches à flèche (curseur) effacera l'opération. S'il semble que le menu n'a pas réalisé ce que vous souhaitez, vérifiez s'il attend le clic de position. Pour les détails, voyez Section 6.2 [Actions], page 45.

En pressant `Btn3` dans la zone de Dessin affiche aussi un menu avec beaucoup des opérations les plus courantes (excepté lorsque vous êtes au milieu d'un dessin d'une ligne ou d'un arc). Lorsqu'un choix dans le menu déroulant du `Btn3` a besoin d'une position de curseur, il utilise la position où se trouve le curseur lorsque le `Btn3` était pressé. Par exemple, pour obtenir l'information détaillée sur un objet, placez le pointeur sur l'objet, pressez `Btn3`,

puis choisissez ‘**object report**’. Si vous déroulez le menu *Btn3* mais ne voulez pas effectuer une des actions, cliquez sur un des en-têtes du menu.

Fichier Ce menu offre un choix de chargement, sauvegarde et d’impression de données, sauvegarder l’information de connexion dans un fichier ou quitter l’application. La plupart des entrées dans le menu **Fichier** sont self explanatory. En sélectionnant ‘**print layout**’, une boîte de dialogue d’impression apparaît. Une sélection de plusieurs pilotes est disponible depuis le dialogue de contrôle d’imprimante. *PostScript*, *encapsulated PostScript* et *GerberX* sont actuellement supportés. Le pilote *GerberX* produit tous les fichiers nécessaires pour permettre une industrialisation professionnelle de la carte. Les fonctionnalités de sauvegarde de la connexion dans le menu **Fichier** produit des sorties dans un format spécifique qui n’est pas très utile. Ils ne produisent *pas* de fichiers de netlist.

Éditer Le menu **Édition** fournit les habituels couper, copier, coller qui fonctionnent sur les sélections. Pour apprendre comment créer des sélections complexes, voyez Section 3.10 [Arrow Tool], page 28. Le menu **Édition** fournit aussi un accès aux Défaire et Refaire de la dernière opération. Ceci peut aussi être accompli avec la touche *U* et *Shift-R*. Finalement, le menu **Édition** vous permet de changer les noms de: la couche, de la couche active ou des objets texte sur la couche.

Écran Le menu **Ecran** supporte la plupart des fonctions liées à la zone des Couches. Il existe plusieurs entrées pour changer la grille, le facteur de zoom et quel type de nom d’élément est affiché avec des valeurs populaires. Vous pouvez aussi réaligner l’origine de la grille et tracer ou enlever l’affichage de la grille. Avant le changement de l’alignement de la grille, je vous recommande d’agrandir au maximum pour vous assurer que les points de la grille apparaissent exactement o vous le souhaitez.

Le menu **Ecran** vous permet aussi de valider ou non la visibilité de la couche du masque de soudure. Lorsque la couche du masque de soudure est rendue visible, il obscurcit la plupart du schéma, il ne faut donc le rendre visible que lorsque vous voulez voir à quoi va ressembler le masque. Le masque de soudure que vous voyez appartient au côté de la carte que vous visualisez, qui peut être changé avec l’option ‘**view solder side**’, aussi disponible dans le menu **Ecran**. Lorsque le masque de soudure est affiché, les ajustements de dégagement de broche et de pastille (see Section 2.5 [Line Objects], page 8) altèrent la taille des perçages du masque.

Tailles Le menu **Sizes** vous permet de sélectionner un groupe d’épaisseur de lignes, de diamètres de de vias, de taille de perçage de vias et de dégagement (keepaway) (collectivement appelé un "style de routage") devant être copié dans les tailles "actives". Vous pouvez aussi changer les noms donnés aux styles de routage et ajuster leur valeurs depuis ce menu. Les tailles "active" sont montrées dans le ligne de statut et contrôlent la taille initiale des nouveaux vias, des trous de perçage, des lignes, des dégagements, des objets texte et aussi les dimensions maximum de la carte.

Configuration

Le menu **Configuration** contrôle plusieurs paramètres d'opérations de configuration. L'entrée 'edit layer groups' fournit un dialogue qui vous permet de changer la manière dont les couches sont groupées. Le groupement des couches est décrit dans Section 2.4 [Layer Objects], page 7. L'entrée 'all-direction lines' contrôle l'arrondissement des lignes avec un angle à 45 degrés. Vous pouvez aussi contrôler si le déplacement d'objets individuels implique que les lignes qui y sont attachées "rubber band" avec le déplacement ou pas depuis le menu **Configuration**. Une autre entrée contrôle si l'angle de départ du clip pour le mode deux lignes (see Section 2.5 [Line Objects], page 8) alterne à chaque nouvelle ligne. Vous pouvez aussi contrôler si les noms d'éléments doivent être uniques depuis le menu **Configuration**. Lorsque les noms d'éléments unique sont validés, copier un nouvel élément créera automatiquement un nom unique par 'nom de couche' si le nom originel se termine avec un digit (*i.e.* U7 ou R6). Le menu **Configuration** vous permet de contrôler si le curseur accroche les broches et les pastilles même lorsqu'elles sont hors grille. Finalement, vous pouvez contrôler si les nouvelles lignes et arcs touchent ou effacent les polygones en contact depuis se menu.

Selection Ce menu couvre la plupart des opérations qui fonctionnent avec les objets sélectionnés. Vous pouvez soit (dé)sélectionner tous les objets visibles sur une couche ou seulement celles qui ont été trouvées par la dernière recherche de connexion, voyez . Vous pouvez effacer tous les objets sélectionnés depuis ce menu. Les autres entrées du menu **Sélection** changent les tailles des objets sélectionnés. Notez qu'une action de sélection n'affecte que les objets qui sont sélectionnés *et* ont leur visibilité validée sur le panneau du contrôle de couche. Le menu **Sélection** fournit aussi un moyen pour sélectionner les objets par nom en utilisant les Appendix C [Regular Expressions], page 82 d'Unix.

Tampon Depuis le menu **Tampon**, vous pouvez sélectionner un des cinq tampons à utiliser, pivoter ou effacer le contenu ou sauvegarder le contenu du tampon dans un fichier. Vous pouvez aussi utiliser l'entrée 'break buffer element to pieces' pour décomposer un élément en pièces pour l'édition. Note: seuls les objets avec une visibilité validée sont copiés dans le schéma. Si vous avez quelque chose dans un tampon, vous pouvez alors changer le côté de la carte que vous regardez, le contenu du tampon aura automatiquement un miroir pour être collé sur le côté que vous regardez. Il n'est pas nécessaire d'effacer un tampon avant de couper ou copier quelque chose dedans -il sera automatiquement effacé.

Connexion

Les entrées disponibles par le menu **Connexion** vous permettent de trouver les connexions depuis les objets et de les manipuler. Vous pouvez aussi optimiser ou effacer les liaisons depuis ce menu. Finalement l'entrée 'auto-route all rats' vous permet de router toutes les connexions montrée par les liaisons. Le routeur utilisera toutes les couches de cuivre visible pour le routage, désactivez donc la visibilité de toutes les couches que vous ne voulez pas utiliser. Le routeur comprendra automatiquement et évitera toutes les pistes qui sont déjà sur la carte mais il n'est pas restreint à la grille. Finalement, le routeur fait son routage en

utilisant les tailles actives (excepté pour les liaisons qui ont un style de routage défini). Pcb sait toujours quelles pistes sont routées par le routeur et vous pouvez les enlever sélectivement sans peur de changer les pistes que vous avez routé manuellement avec l'entrée '`rip-up all auto-routed tracks`' dans le menu **Connexion**. L'entrée '`design rule checker`' fonctionne pour contrôler les zones de cuivre qui sont trop proches ensemble et les connexions qui s'approchent de trop pour une production fiable. Le DRC stoppe lorsque le premier problème est rencontré donc, après avoir réglé le problème, assurez-vous de le relancer jusqu'à ce qu'aucun problème ne soit trouvé.

Warning: **COPPER TEXT IS IGNORED BY THE DRC CHECKER.**

Info L'entrée '`generate object report`' depuis le menu **Info** fournit une manière d'obtenir une information détaillée sur un objet, telle que ses coordonnées, ses dimensions, etc. Vous pouvez aussi obtenir un rapport résumant tous les percages utilisés sur la carte avec '`generate drill summary`'. Enfin, vous pouvez avoir une liste de toutes les broches, pastilles et vias trouvés pendant une recherche de connexion.

Fenêtre Le menu **Fenêtre** fournit une manière de montrer chaque fenêtre de Pcb en avant. La fenêtre *Bibliothèque* est utilisée pour fournir les éléments dans le tampon coller. La fenêtre *Journal des messages* contient les divers messages que Pcb envoie à l'utilisateur. La fenêtre *Netlist* montre la liste des connexions désirées.

Maintenant que vous êtes familiers avec les divers menus, il est temps de pratiquer. Depuis le menu **Fichier**, choisissez '`chargement du schéma`', naviguez dans le répertoire du tutoriel, puis chargez le fichier '`tut1.pcb`'.

3.1.2 La ligne de statut et le champ d'entre

La ligne de statut est située sur le bord bas de la fenêtre principale. Pendant mes opérations normales, l'information de statut est visible ici. Lorsqu'une opération de menu sélectionne nécessite un clic de bouton additionnel, la ligne de statut est remplacée par un message vous indiquant la position du curseur et cliquez. Lorsqu'une entrée de texte est nécessaire, la ligne de statut est remplacée par un champ d'entre qui possède un prompt pour saisir l'entre.

La ligne de statut montre, de la gauche à la droite, le ct de la carte que vous voyez (la touche *Tab* change ceci), les valeurs de grilles courantes, si les nouvelles lignes sont limitées à 45 degrés, quel type de mode de ligne à 45 degrés est actif, si le rubberband se déplace et si le mode de rotation est activé (R) et le facteur de zoom. Cette information est suivie par la largeur de ligne active, la taille des vias et des trous de perçage, les espaces de dégagements et la taille des textes. En dernier vient le numéro de tampon actif et le nom de la couche. Un astisque apparaît complètement à gauche pour indiquer que la couche a été modifiée depuis la dernière sauvegarde. Notez que le nom de la couche n'est pas la même chose que le nom de fichier du schéma. Changez le facteur de grille à 1.0 mm depuis le menu **cran**. Observez comment la ligne de statut montre les nouvelles paramètres de grille. Excepté pour le cas de la grille métrique, toutes les dimensions dans la ligne de statut sont en unités de 0.001 inch (1 mil).

The input-field pops up (temporarily replacing the status-line) whenever user input is required. Two keys are bound to the input field: the *Escape* key aborts the input, *Return* accepts it. Let's change the name of a component on the board to see how the input-field

works. Position the cross hair over R5, and press the *N* key. The input field pops-up showing the name for you to edit. Go ahead and change the name, then hit return. Notice the name of the element changed. Now undo the change by pressing the *U* key. You can position the cross hair over the name, or the element before pressing the *N* key.

Now select ‘realign grid’ from the **Screen** menu. Notice that the status line has been replaced with an instruction to position the cursor where you want a grid point to fall. In this case, since the cross hair can only fall on a grid point, you must move the tip of the finger cursor to the place where you want a grid point to appear. Do not worry that the cross hair is not coincident with the cursor. Click *Btn1* at your chosen location. See how the grid has shifted, and the status line has returned.

The present cross hair position is displayed in the upper right corner of the window. Normally this position is an absolute coordinate, but you can anchor a marker at the cross hair location by pressing *Ctrl-M* (try it now) and then the display will read both the absolute cross hair position as well as the difference between it and the marker. The numbers enclosed in < > are the X and Y distances between the cross hair and the mark, while the numbers enclosed in parenthesis are the distance and angle from the mark to the cross hair. The values displayed are always in units of 0.001 inch (1 mil). Pressing *Ctrl-M* again turns the marker off.

3.1.3 The Panner Control

The panner control, located at the upper left side of the window, is used to adjust what portion of the layout is seen in the Layout area. The outer rectangle of the panner represents the whole layout (extended to have the panner aspect ratio), while the inner control rectangle represents the portion seen through the Layout area. Slowly drag this part around with the mouse (*Btn1*) to see how it pans the layout. Release the panner control, but leave the pointer within the outer most rectangle of the control. Now hit a few keyboard arrow keys. Each arrow key moves the region seen one-half window size in the arrow direction. If you want to see a portion of the layout that is off the top of the screen, you need to drag the panner up, or hit the up arrow key.

Move the pointer back into the Layout area. Increase the zoom by hitting the *Z* key. See how the inner part of the panner becomes smaller to reflect that you are viewing a smaller part of the layout. Now zoom out by hitting *Shift-Z*. If you hit the arrow key with the pointer in the Layout area, it moves the pointer rather than scrolling the window. In general the keyboard shortcuts depend on which region of **Pcb**'s window the pointer is over. For the most part, the key strokes in this manual refer to the case when the pointer is in the Layout area. You can do fine scrolling in the Layout area by dragging it directly with the Panner tool. Press the *Escape* key to select the panner tool. Now drag in the layout area with *Btn1* down. You can scroll the drawing window while the pointer is inside it with *Mod-Arrow* keys.

If you are moving or drawing an object and go beyond the drawing window borders, the window will auto-scroll. If you want to stop the auto-scrolling while the pointer is outside the Layout area, simply pass the pointer briefly over the panner control area, or a menu button.

Another way to navigate around a layout is with *Shift-Btn3*. When pressed down, the layout will zoom so the whole extent of objects is visible, and will return to the previous zoom when you release the button, but will be centered at the cross hair position where the

button is released. You can do this while in the middle of drawing an object. Try it now to center near U7.

3.1.4 The Layer Controls

The layer control panel, located below the panner control, is used to turn on and off the display of layer groups and to select the active drawing layer. If a layer hasn't been named, the label "*(unknown)*" is used as the default. If this happens, it probably means the application resources are not installed properly.

The upper buttons are used to switch layers on and off. Click *<Btn1>* on one or more of them. Each click toggles the setting. If you turn off the currently active layer, another one that is visible will become active. If there are no others visible, you will not be able to turn off the active layer. When the layers are grouped, clicking on these buttons will toggle the visibility of all layers in the same group. This is a good idea because layers in the same group reside on the same physical layer of the actual board. Notice that this example has 2 groups each having 3 layers, plus two other layers named 'unused'. Use the 'Edit layer groups' option in the 'Settings' menu to change the layer groupings. Note that changing the groupings can radically alter the connectivity on the board. Grouping layers is only useful for helping you to color-code signals in your layout. Note that grouping layers actually reduces the number of different physical layers available for your board, so to make an eight layer board, you cannot group any layers.

The *far side* button turns on and off the visibility of elements (including SMD pads) on the opposite (to the side you're viewing) board side, as well as silk screening on that side. It does not hide the x-ray view of the other copper layers, these must be turned off separately if desired. Use the *tab* key to view the entire board from the other side. To see a view of what the back side of the board will actually look like, make the solder layer the active layer then press *tab* until the status line says "solder" on the right, then turn off the visibility of all layers except solder, pins/pads, vias, and silk. Now turn them all back on.

The lowest button, named *active*, is used to change the active drawing layer. Pressing *<Btn1>* on it pops up a menu to select which layer should be active. Each entry is labeled with the layer's name and drawn in its color. The active layer is automatically made visible. The active layer is always drawn on top of the other layers, so the ordering of layers on the screen does not generally reflect the ordering of the manufactured board. Only the solder, component, silkscreen, and solder-mask layers are always drawn in their physical order. Bringing the active layer to the top makes it easier to select and change objects on the active layer. Try changing the active layer's name to *ABC* by selecting 'edit name of active layer' from the 'Edit' menu. Changing the active layer can also be done by pressing keys *1..MAX_LAYER*.

Turn off the visibility of the component layer. Now make the component layer the active layer. Notice that it automatically became visible. Try setting a few other layers as the active layer. You should also experiment with turning on and off each of the layers to see what happens.

The netlist layer is a special layer for adding connections to the netlist by drawing rat lines. This is not the recommended way to add to the netlist, but occasionally may be convenient. To learn how to use the netlist layer see Section 2.9 [Net Objects], page 10.

3.1.5 The Tool Selectors

The tool selector buttons reside below the layer controls. They are used to select which layout tool to use in the drawing area. Each tool performs its function when *Btn1* is pressed. Every tool gives the cursor a unique shape that identifies it. The tool selector buttons themselves are icons that illustrate their function. Each layout tool can also be selected from the keyboard:

<i>Escape</i> key	Panner tool
<i>F1</i> key	Via tool
<i>F2</i> key	Line tool
<i>F3</i> key	Arc tool
<i>F4</i> key	Text tool
<i>F5</i> key	Rectangle tool
<i>F6</i> key	Polygon tool
<i>F7</i> key	Buffer tool
<i>F8</i> key	Delete tool
<i>F9</i> key	Rotate tool
<i>Insert</i> key	Insert-point tool
<i>F10</i> key	Thermal tool
<i>F11</i> key	Arrow tool
<i>F12</i> key	Lock tool

Some of the tools are very simple, such as the Via tool. Clicking *Btn1* with the Via tool creates a via at the cross hair position. The via will have the diameter and drill sizes that are active, as shown in the status line. The Buffer tool is similar. With it, *<Btn1>* copies the contents of the active buffer to the layout, but only those parts that reside on visible layers are copied. The Rotate tool allows you to rotate elements, arcs, and text objects 90 degrees counter-clockwise with each click. Holding the *Shift* key down changes the Rotate tool to clockwise operation. Anything including groups of objects can be rotated inside a buffer using the rotate buffer menu option.

The Line tool is explained in detail in Section 2.5 [Line Objects], page 8. Go read that section if you haven't already. Activate the Line tool. Set the active layer to the solder layer. Try drawing some lines. Use the *U* key to undo some of the lines you just created. Zoom in a bit closer with the *Z* key. Draw some more lines. Be sure to draw some separate lines by starting a new anchor point with *Ctrl-Btn1*. Change the 'crosshair snaps to pin/pads' behavior in the **Settings** menu. Now draw a line. Notice that the new line points must now always be on a grid point. It might not be able to reach some pins or pads with this setting. Increase the active line thickness by pressing the *L* key. Note that the status line updates to reflect the new active line thickness. Now draw another line. Before completing the next line, make the component layer active by pressing the *4* key. Now finish the line. Notice that a via was automatically placed where you switched layers. Pcb does not do any checks to make sure that the via could safely be placed there. Neither does it interfere with your desire to place lines haphazardly. It is up to you to place things properly when doing manual routing with the Line tool.

The Arc tool is explained in detail in Section 2.6 [Arc Objects], page 9. Its use is very similar to the Line tool.

The Rectangle tool, Polygon tool and Thermal tool are explained in detail in Section 2.7 [Polygon Objects], page 9. Go read that section. Remember that the Thermal tool will only create and destroy thermals to polygons on the active layer. Use the Rectangle tool to make a small copper plane on the component layer. Now place a via in the middle of the plane. Notice that it does not touch the plane, and they are not electrically connected. Use the Thermal tool to make the via connect to the plane. Thermals allow the via or pin to be heated by a soldering iron without having to heat the entire plane. If solid connections were made to the plane, it could be nearly impossible to solder. Click on the via again with the Thermal tool to remove the connection to the plane.

The Insert-point tool is an editing tool that allows you to add points into lines and polygons. The Insert-point tool enforces the 45 degree line rule. You can force only the shorter line segment to 45 degrees by holding the *Shift* key down while inserting the point. Try adding a point into one of the lines you created. Since line clipping is turned on, you may need to move the cross hair quite far from the point where you first clicked on the line. Turn off the line clipping by selecting ‘all-direction lines’ from the **Settings** menu (or hit the *Period* key). Now you can place an inserted point anywhere. Try adding a point to the rectangle you made earlier. Start by clicking somewhere along an edge of the rectangle, then move the pointer to a new location and click again.

The delete-mode deletes the object beneath the cursor with each *Btn1* click. If you click at an end-point that two lines have in common, it will replace the two lines with a single line spanning the two remaining points. This can be used to delete an "inserted" point in a line, restoring the previous line. Now delete one of the original corner points of the polygon you were just playing with. To do this, place the cross hair over the corner and click on it with the Delete tool. You could also use the *Backspace* key if some other tool is active. Try deleting some of the lines and intermediate points that you created earlier. Use undo repeatedly to undo all the changes that you’ve made. Use redo a few times to see what happens. Now add a new line. Notice that you can no longer use redo since the layout has changed since the last undo happened. The undo/redo tree is always pruned in this way (*i.e.* it has a root, but no branches).

The Arrow tool is so important, it has its own section: Section 3.10 [Arrow Tool], page 28. Go read it now.

The Lock tool allows you to lock objects on the layout. When an object is locked, it can’t be selected, moved, rotated, or resized. This is useful for very large objects like ground planes, or board-outlines that are defined as an element. With such large objects, nearly anywhere you click with the Arrow tool will be on the large object, so it could be hard to draw box selections. If you lock an object, the Arrow tool will behave as if it didn’t exist. You cannot unlock an object with undo. You must click on it again with the Lock tool. If an object is locked, previous changes to it cannot be undone either. When you lock an object, a report message about it is popped up and will always tell you what object it is, and that it is locked if you just locked it. Other than noticing your inability to manipulate something, the only way to tell an object is locked is with a report from the **Info** menu. Use the Lock tool sparingly.

3.1.6 Layout Area

The layout area is where you see the layout. The cursor shape depends on the active tool when the pointer is moved into the layout area. A cross hair follows the X11 pointer with

respect to the grid setting. Select a new grid from the *Screen* menu. The new value is updated in the status line. A different way to change the grid is *Shift<Key>g* to decrease or *<Key>g* to increase it, but this only works for English (integer mil) grids. The grid setting is saved along with the data when you save a pcb layout. For homemade layouts a value around 50 is a good setting. The cursor can also be moved in the layout area with the cursor (arrow) keys or, for larger distances, by pressing the *Shift* modifier together with a cursor key.

3.2 Log Window

This optional window is used to display all kind of messages including the ones written to *stderr* by external commands. The main advantage of using it is that its contents are saved in a scrolling list until the program exits. Disabling this feature by setting the resource *useLogWindow* to *false* will generate popup windows to display messages. The *stderr* of external commands will appear on *Pcbs stderr* which normally is the parent shell. I suggest you iconify the log window after startup for example by setting **log.iconic* to *true* in the resource file. If *raiseLogWindow* is set *true*, the window will deiconify and raise itself whenever new messages are to be displayed.

3.3 Library Window

The library window makes loading elements (or even partial layouts) easy. Just click the appropriate library from the list on the left. A list of its elements then appears on the right. Select an element from the list by clicking on its description. Selecting an element from the library will also automatically copy the element into the active buffer, then invoke the *Buffer* tool so you can paste it to the layout. Elements in the old library should be taken with a grain of salt (*i.e.* check them carefully before using). The old library names all begin with *~* so you can easily distinguish between the old and new libraries. All of the elements in the new library should be thoroughly vetted, so you can use them with confidence. The new libraries are stored simply as directories full of element files, so making additions to the new library is easy since there is no need to learn m4. For details on the old libraries, check-out Section 7.7 [Library File], page 62 and Section 7.6 [Library Contents File], page 62. For details on the format of an element file used for the new libraries, see Section 7.3 [Element File], page 59.

3.4 Netlist Window

The netlist window is very similar to the library window. On the left is a list of all of the nets, on the right is the list of connections belonging to the chosen net. The chosen net is highlighted in the list and also shown on the second line of the window in red. If the net name has a star to the left of it then it is "disabled". A disabled net is treated as if it were not in the net list. This is useful, for example, if you plan to use a ground plane and don't want the ground net showing up in the rat's nest. You can enable/disable individual nets by double-clicking the net name. If you want to enable or disable all nets at once, there are two buttons at the top of the netlist window for this purpose.

The button labeled 'Sel Net On Layout' can be used to select (on the layout) everything that is connected (or is supposed to be connected) to the net. If you click on a connection in the connection list, it will select/deselect the corresponding pin or pad in the layout and

also center the layout window where it is located. If you "Find" ('lookup connection to object' in the **Connects** menu [also *F* key]), a pin or pad it will also choose the net and connection in the netlist window if it exists in the netlist.

If no netlist exists for the layout, then the netlist window does not appear. You can load a netlist from a file from the **File** menu. The format for netlist files is described in Section 7.5 [Fichier Netlist], page 61.

3.5 Drawing and Removing Basic Objects

hace begging gutting here, and do a real-world tutorial example.

There are several ways of creating new objects: you can draw them yourself, you can copy an existing object (or selection), or you can load an element from a file or from the Library window. Each type of object has a particular tool for creating it.

The active tool can be selected from the tool selectors in the bottom left corner or by one of the function keys listed earlier in this chapter. Each *<Btn1>* press with the tool tells the application to create or change the appropriate object or at least take the first step to do so. Each tools causes the cursor to take on a unique shape and also causes the corresponding tool selector button to be highlighted. You can use either cue to see which tool is active.

Insert mode provides the capability of inserting new points into existing polygons or lines. The 45 degree line clipping is now enforced when selected. Press and hold the shift key while positioning the new point to only clip the line segment to the nearer of the two existing points to 45 degrees. You can also toggle the 45-degree clipping in the middle of a point insertion by pressing the *<Key>*. If the shift key is not depressed and the 45 degree line clipping mode is on, both new line segments must be on 45 degree angles - greatly restricting where the new point may be placed. In some cases this can cause confusion as to whether an insertion has been started since the two new lines may be forced to lie parallel on top of the original line until the pointer is moved far from the end points.

Removing objects, changing their size or moving them only applies to objects that are visible when the command is executed.

There are several keystrokes and button events referring to an *object* without identifying its type. Here's a list of them:

<Btn1> creates (or deletes) an object depending on the current mode.

<Key>BackSpace or *<Key>Delete* removes the visible object at the cursor location. When more than one object exists at the location, the order of removal is: via, line, text, polygon and element. The drawn layer order also affects the search - whatever is top - most (except elements) is affected before lower items. Basically all this means that what is removed is probably just what you expect. If for some reason it isn't, undo and try again. Only one object is removed for each keystroke. If two or more of the same type match, the newest one is removed.

Use *<Key>s* and *Shift<Key>s* to change the size (width) of lines, arcs, text objects, pins, pads and vias, or to toggle the style of polygons (whether pins and vias automatically have clearances).

<Key>n changes the name of pins, pads, vias, the string of a text object, or the currently displayed label of an element.

$\langle Key \rangle m$ moves the line, arc, or polygon under the cross hair to the active layer if it wasn't on that layer already.

$\langle Key \rangle u$ (undo) recovers from an unlimited number of operations such as creating, removing, moving, copying, selecting etc. It works like you'd expect even if you're in the midst of creating something.

$Shift \langle Key \rangle r$ restores the last undone operation provided no other changes have been made since the undo was performed.

$\langle Key \rangle tab$ changes the board side you are viewing.

For a complete list of keystrokes and button events see Section 6.3 [Translations], page 55.

3.5.1 Lines

To draw new lines you have to be in *line-mode*. Get there either by selecting it from the *Tool palette* or by pressing $\langle Key \rangle F2$. Each successive *notify* event creates a new line. The adjustment to 45 degree lines is done automatically if it is selected from the *Display* menu. You can toggle the 45 degree mode setting by pressing the $\langle Key \rangle$. (That is the period key). When 45 degree enforcement is turned on there are three distinct modes of line creation: a single line on the closest 45 degree vector towards the cross hair (but not necessarily actually ending at the cross hair), two lines created such that the first leaves the start point on a 90 degree vector and the second arrives at the cross hair on a 45 degree vector, and finally two lines created such that the first leaves the start point on a 45 degree vector and the second arrives at the cross hair on a 90 degree vector. These last two modes always connect all the way from the start and end points, and all lines have angles in 45 degree multiples. The $\langle Key \rangle /$ cycles through the three modes. The status line shows a text icon to indicate which of the modes is active and the lines following the cross hair motion show the outline of the line(s) that will actually be created. Press $\langle Key \rangle Escape$ to leave line-mode.

$\langle Key \rangle l$, $Shift \langle Key \rangle l$ and the entries in the *Sizes* menu change the initial width of new lines. This width is also displayed in the status line.

3.5.2 Arcs

An Arc is drawn with the *arc-tool*. Get there either by selecting it from the *Tool palette* or by pressing $\langle Key \rangle F8$. Press *Btn1* to define the starting point for the arc. Drag the mouse towards the desired end point along the path you want the arc to follow. The outline of the arc that will be created is shown on the screen as you move the mouse. Arcs are always forced to be 90 degrees and have symmetrical length and width (i.e. they are a quarter circle). The next *Btn1* click creates the arc. It will have the same width as new lines (displayed in the status line) and appear on the active layer. The arc leaves the starting point towards the cross hair along the axis whose distance from the cross hair is largest. Normally this means that if you drag along the path you want the arc to follow, you'll get what you want. If the grid is set to the arc radius, then the two distances will be equal and you won't be able to get all of the possible directions. If this is thwarting your desires, reduce the grid spacing ($!Shift \langle Key \rangle G$) and try again.

3.5.3 Polygons and Rectangles

A polygon is drawn by defining all of its segments as a series of consecutive line segments. If the first point matches a new one and if the number of points is greater than two, then

the polygon is closed. Since matching up with the first point may be difficult, you may use *Shift<Key>p* to close the polygon. The *Shift<Key>p* won't work if clipping to 45 degree lines is selected and the final segment cannot match this condition. I suggest you create simple convex polygons in order to avoid a strong negative impact on the performance of the connection scanning routines. The *rectangle-mode* is just an easy way to generate rectangular polygons. *Polygon-mode* also is selected by *<Key>F6* whereas *rectangle-mode* uses *<Key>F4*. Pressing a *<Btn1>* at two locations creates a rectangle by defining two of its corners. *<Key>Insert* brings you to *insert-point-mode* which lets you add additional points to an already existing polygon. Single points may be removed by moving the cross hair to them and selecting one of the delete actions (*remove-mode*, *BackSpace*, or *Delete*). This only works if the remaining polygon will still have three or more corners. Pressing *<Key>u* or *<Key>p* while entering a new polygon brings you back to the previous corner. Removing a point does not force clipping to 45 degree angles (because it's not generally possible). Newly created polygons will not connect to pins or vias that pierce it unless you create a thermal (using the thermal mode) to make the connection. If the edge of a polygon gets too close to a pin or via that lies outside of it, a warning will be issued and the pin will be given a special color. Increasing the distance between them will remove the warning color.

3.5.4 Text

Pressing *<Key>F5* or clicking one of the text selector buttons changes to *text-mode*. Each successive notify event (*<Btn1>*) pops up the input line at the bottom and queries for a string. Enter it and press *<Key>Return* to confirm or *<Key>Escape* to abort. The text object is created with its upper left corner at the current pointer location. The initial scaling is changed by *<Key>t* and *Shift<Key>t* or from the *Sizes* menu.

Now switch to *rotate-mode* and press *<Btn1>* at the text-objects location. Text objects on the solder side of the layout are automatically mirrored and flipped so that they are seen correctly when viewing the solder-side.

Use *<Key>n* to edit the string.

TEXT OBJECTS ON COPPER LAYERS CREATE COPPER LINES BUT THEY ARE NOT SCANNED FOR CONNECTIONS. If they are moved to the silkscreen layer, they no longer create copper.

3.5.5 Vias

The initial size of new vias may be changed by *<Key>v* and *Shift<Key>v* or by selecting the appropriate entry from the *Sizes* menu. *Mod1<Key>v* and *Mod1 Shift<Key>v* do the same for the drilling hole of the via. The statusline is updated with the new values. Creating a via is similar to the other objects. Switch to *via-mode* by using either the selector button or *<Key>F1* then press *<Key>]* or *<Btn1>* to create one. *<Key>n* changes the name of a via. If you want to create a mounting hole for your board, then you can place a via where you want the hole to be then convert the via into a hole. The conversion is done by pressing *!Ctrl<Key>h* with the cross hair over the via. Conceptually it is still a via, but it has no copper annulus. If you create such a hole in the middle of two polygons on different layers, it will short the layers. Theoretically you could arrange for such a hole not to be plated, but a metal screw inserted in the hole would still risk shorting the layers. A good rule is to realize that holes in the board really are vias between the layers and so place them where

they won't interfere with connectivity. You can convert a hole back into a normal via with the same keystroke used to convert it in the first place.

3.5.6 Elements

Some of the functions related to elements only work if both the package layer and the pin layer are switched on.

Now that you're familiar with many of the basic commands, it is time to put the first element on the layout. First of all, you have to load data into the paste buffer. There are four ways to do this:

- 1) load the data from a library
- 2) load the data from a file
- 3) copy data from an already existing element
- 4) convert objects in the buffer into an element

We don't have any elements on the screen yet nor anything in the buffer, so we use number one.

Select *lsi* from the menu in the library window press `<Btn1>` twice at the appropriate text-line to get the MC68030 CPU. The data is loaded and the mode is switched to *pastebuffer-mode*. Each notify event now creates one of these beasts. Leave the mode by selecting a different one or by `<Key>Escape` which resets all modes.. The cross hair is located at the *mark* position as defined by the data file. Rotating the buffer contents is done by selecting the *rotate* entry of the *Buffer* menu or by pressing `Shift<Key>F3`. The contents of the buffer are valid until new data is loaded into it either by a cut-to-buffer operation, copy-to-buffer operation or by loading a new data file. There are 5 buffers available (possibly more or less if changed at compile time with the `MAX_BUFFER` variable in 'globalconfig.h'). Switching between them is done by selecting a menu entry or by `Shift<Key>1..MAX_BUFFER`. Each of the two board sides has its own buffers.

The release includes all data files for the circuits that are used by the demo layout. The elements in the LED example are not found in the library, but you can lift them from the example itself if you want. If you have problems with the color of the cross hair, change the resource *cross hairColor* setting to a different one.

Now load a second circuit, the MC68882 FPU for example. Create the circuit as explained above. You now have two different unnamed elements. Unnamed means that the layout-name of the element hasn't been set yet. Selecting *description* from the *Display* menu displays the description string of the two circuits which are CPU and FPU. The values of the circuits are set to MC68030 and MC68882. Each of the names of an element may be changed by `<Key>n` at the elements location and editing the old name in the bottom input line. Naming pins and vias is similar to elements. You can hide the element name so that it won't appear on the board silkscreen by pressing `<key>h` with the cursor over the element. Doing so again un-hides the element name.

Entering `:le` and selecting an element data file is the second way to load circuits.

The third way to create a new element is to copy an existing one. Please refer to Section 3.6 [Moving and Copying], page 26.

The fourth way to create a new element is to convert a buffer's contents into an element. Here's how it's done: Select the Via-tool from the *Tool pallet*. Set the grid spacing to something appropriate for the element pin spacing. Now create a series of vias where the

pins go. Create them in pin number order. It is often handy to place a reference point (*!Ctrl<Key>m*) in the center of the first pin in order to measure the location of the other pins. Next make a solder-side layer the active layer from the *active-layer* popup menu. Now draw the outline of the element using lines and arcs. When you're done, select everything that makes up the element with a box selection (*<Btn3Down> drag, <Btn3Up>*). Now select "cut selection to buffer" from the *Buffer* menu. Position the cursor over the center of pin 1 and press the left button to load the data into the buffer. Finally select "convert buffer to element" from the *Buffer* menu. You'll only want to create elements this way if they aren't already in the library. It's also probably a good idea to do this before starting any of the other aspects of a layout, but it isn't necessary.

To display the pinout of a circuit move to it and press *Shift<Key>d* or select *show pinout* from the *Objects* menu. A new window pops up and displays the complete pinout of the element. This display can be difficult to read if the component has been rotated 90 degrees :- (therefore, the new window will show an un-rotated view so the pin names are readable. *<Key>d* displays the name of one or all pins/pads inside the Layout area, this is only for display on-screen, it has no effect on any printing of the layout.

You also may want to change a pin's or pad's current size by pressing *<Key>s* to increase or *Shift<Key>s* to decrease it. While this is possible, it is not recommended since care was probably taken to define the element structure in the first place. You can also change the thickness of the element's silkscreen outline with the same keys. You can change whether a pin or SMD pad is rounded or square with the *<Key>q*. SMD pads should usually have squared ends. Finally, you can change whether the non-square pins are round or octagonal with the *!Ctrl<Key>o*.

SMD elements and silkscreen objects are drawn in the "invisible object" color if they are located on the opposite side of the board.

For information on element connections refer to Section 3.9 [Connection Lists], page 28.

3.5.7 Pastebuffer

The line-stack and element-buffer of former releases have been replaced by 5 (possibly more or less if changed at compile time with the `MAX_BUFFER` variable in 'globalconfig.h') multi-purpose buffers that are selected by *Shift<Key>1..MAX_BUFFER*. The status line shows which buffer is the active one. You may load data from a file or layout into them. Cut-and-paste works too. If you followed the instructions earlier in this chapter you should now have several objects on the screen. Move the cross hair to one of them and press *<Btn3Down>* to toggle its selection flag. (If you drag the mouse while the button is down, a box selection will be attempted instead of toggling the selection.) The object is redrawn in a different color. You also may want to try moving the pointer while holding the third button down and release it on a different location. This selects all objects inside the rectangle and unselects everything else. If you want to add a box selection to an existing selection, drag with *Mod1<Btn3Down>* instead. Dragging *Shift Mod1<Btn3Down>* unselects objects in a box. Now change to *pastebuffer-mode* and select some operations from the *Buffer* menu. Copying objects to the buffer is available as *Mod1<Key>c* while cutting them uses *Mod1<Key>x* as shortcut. Both clear the buffer before new data is added. If you use the menu entries, you have to supply a cross hair position by pressing a mouse button. The objects are attached to the pastebuffer relative to that cross hair location. Element data or PCB data may be

merged into an existing layout by loading the datafiles into the pastebuffer. Both operations are available from the *File* menu or as user commands.

3.6 Moving and Copying

All objects can be moved including element-names, by *<Btn2Down>*, dragging the pointer while holding the button down and releasing it at the new location of the object. If you use *Mod1<Btn2Down>* instead, the object is copied. Copying does not work for element-names of course. You can move all selected objects with *Shift <Btn1>*. This uses the Pastebuffer, so it will remove whatever was previously in the Pastebuffer. Please refer to Section 3.5.7 [Pastebuffer], page 25. If you want to give a small nudge to an object, but you don't think that the mouse will give you the fine level of control that you want, you can position the cursor over the object, press *<Key>* [, move it with the arrow keys, then press *<Key>*] when it's at the desired position. Remember that all movements are forced onto grid coordinates, so you may want to change the grid spacing first.

3.7 Loading and Saving

After your first experience with Pcb you will probably want to save your work. *:s name* passes the data to an external program which is responsible for saving it. For details see *saveCommand* in Section 6.1 [Ressources], page 39. Saving also is available from the *File* menu, either with or without supplying a filename. Pcb reuses the last filename if you do not pass a new one to the save routine.

To load an existing layout either select *load layout data* from the *File* menu or use *:l filename*. A file select box pops up if you don't specify a filename. Merging existing layouts into the new one is supported either by the *File* menu or by *:m filename*.

Pcb saves a backup of the current layout depending on the resource *backup*. The file is named *'/tmp/PCB.%i.backup'* by default (this may have been changed at compilation time via the *BACKUP_NAME* variable in *'globalconfig.h'*). During critical sections of the program or when data would be lost it is saved as *'/tmp/PCB.%i.save'*. This file name may be changed at compile time with the *DEFAULT_MEDIASIZE* variable in *'globalconfig.h'*.

%i is replaced by the process ID.

3.8 Printing

Pcb now has support for device drivers, *PostScript*, *encapsulated PostScript*, and *Gerber RS-274-X* drivers are available so far. The *Gerber RS-274-X* driver additionally generates a numerical control (NC) drill file for automated drilling, a bill of materials file to assist in materials procurement and inventory control, and a centroid (X-Y) file which includes the centroid data needed by automatic assembly (pick and place) machines. I recommend the use of *GhostScript* if you don't have a *PostScript* printer for handling the PostScript output. Printing always generates a complete set of files for a specified driver. See the page about the *Print()* action for additional information about the filenames. The control panel offers a number of options. Most of them are not available for Gerber output because it wouldn't make sense, for example, to scale the gerber output (you'd get an incorrectly made board!) The options are:

'device' The top menu button selects from the available device drivers.

- 'rotate' Rotate layout 90 degrees counter-clockwise before printing (default).
- 'mirror' Mirror layout before printing. Use this option depending on your production line.
- 'color' Created colored output. All colors will be converted to black if this option is inactive.
- 'outline' Add a board outline to the output file. The size is determined by the maximum board size changeable from the *sizes* menu. The outline appears on the top and bottom sides of the board, but not on the internal layers. An outline can be useful for determining where to shear the board from the panel, but be aware that it creates a copper line. Thus it has the potential to cause short circuits if you don't leave enough room from your wiring to the board edge. Use a viewer to see what the output outline looks like if you want to know what it looks like.
- 'alignment' Additional alignment targets are added to the output. The distances between the board outline is set by the resource *alignmentDistance*. Alignment targets should only be used if you know for certain that YOU WILL BE USING THEM YOURSELF. It is extremely unlikely that you will want to have alignment targets if you send gerber files to a commercial pcb manufacture to be made.
- 'scaling' It's quite useful to enlarge your printout for checking the layout. Use the scrollbar to adjust the scaling factor to your needs.
- 'media' Select the size of the output media from this menu. The user defined size may be set by the resource *media* either from one of the well known paper sizes or by a X11 geometry specification. This entry is only available if you use X11R5 or later. For earlier releases the user defined size or, if not available, A4 is used. Well known size are:
 - A3
 - A4
 - A5
 - letter
 - tabloid
 - ledger
 - legal
 - executive
- 'offset' Adjust the offsets of the printout by using the panner at the right side of the dialog box. This entry is only available if you use X11R5 or later. A zero offset is used for earlier releases.
- '8.3 filenames' Select this button to generate DOS compatible filenames for the output files. The *command* input area will disappear if selected.
- 'commandline' Use this line to enter a command (starts with |) or a filename. A %f is replaced by the current filename. The default is set by the resource *printCommand*.

The created file includes some labels which are guaranteed to stay unchanged

‘PCBMIN’ identifies the lowest x and y coordinates in mil.

‘PCBMAX’ identifies the highest x and y coordinates in mil.

‘PCBOFFSET’
is set to the x and y offset in mil.

‘PCBSCALE’
is a floating point value which identifies the scaling factor.

‘PCBSTARTDATA’

‘PCBENDDATA’

all layout data is included between these two marks. You may use them with an `awk` script to produce several printouts on one piece of paper by duplicating the code and putting some `translate` commands in front. Note, the normal PostScript units are 1/72 inch.

3.9 Connection Lists

After completing parts of your layout you may want to check if all drawn connections match the ones you have in mind. This is probably best done in conjunction with a net-list file: see Section 3.11 [Rats Nest], page 29. The following examples give more rudimentary ways to examine the connections.

- 1) create at least two elements and name them
- 2) create some connections between their pins
- 3) optionally add some vias and connections to them

Now select *lookup connection* from the *Connections* menu, move the cursor to a pin or via and press any mouse button. Pcb will look for all other pins and/or vias connected to the one you have selected and display the objects in a different color. Now try some of the reset options available from the same menu.

There also is a way to scan all connections of one element. Select *a single element* from the menu and press any button at the element’s location. All connections of this element will be saved to the specified file. Either the layout name of the element or its canonical name is used to identify pins depending on the one which is displayed on the screen (may be changed by *Display* menu).

An automatic scan of all elements is initiated by choosing *all elements*. It behaves in a similar fashion to scanning a single element except the resource *resetAfterElement* is used to determine if connections should be reset before a new element is scanned. Doing so will produce very long lists because the power lines are rescanned for every element. By default the resource is set to *false* for this reason.

To scan for unconnected pins select *unused pins* from the same menu.

3.10 Arrow Tool

Some commands mentioned earlier in this chapter also are able to operate on all selected and visible objects. The Arrow tool is used to select/deselect objects and also to move objects or selections. If you click and release on an object with the Arrow tool, it will

unselect everything else and select the object. Selected objects change color to reflect that they are selected. If you *Shift* click, it will add the object to (or remove) the object from the existing selection. If you drag with the mouse button down with the Arrow tool, one of several things could happen: if you first pressed the button on a selected object, you will be moving the selection to where you release the button. If you first pressed the button on an unselected object, you will be moving that object. If you first pressed the button over empty space, you will be drawing a box to select everything inside the box. The *Shift* key works the same way with box selections as it does with single objects.

Moving a single un-selected object is different from moving a selection. First of all, you can move the end of line, or a point in a polygon this way which is impossible by moving selections. Secondly, if rubber banding is turned on, moving a single object will rubber-band the attached lines. Finally, it is faster to move a single object this way since there is no need to select it first.

You can select any visible object unless it is locked. If you select an object, then turn off its visibility with the Layer controls, it won't be moved if you move the remaining visible selection.

If you have not configured to use strokes in the Pcb user interface, then the middle mouse button is automatically bound to the arrow tool, regardless of the active tool (which is bound to the first mouse button). So using the middle button any time is just like using the first mouse button with the Arrow tool active.

The entries of the *Selection* menu are hopefully self-explanatory. Many of the *Action Commands* can take various key words that make them function on all or some of the selected items.

3.11 Rats Nest

If you have a netlist that corresponds to the layout you are working on, you can use the rats-nest feature to add rat-lines to the layout. First you will need to load a netlist file (see *:rn*, Chapter 4 [Commandes Utilisateur], page 34). *<Key>w* adds rat-lines on the active layer using the current line thickness shown in the status line (usually you'll want them to be thin lines). Only those rat-lines that fill in missing connectivity (since you have probably routed some connections already) are added. If the layout is already completely wired, nothing will be added, and you will get a message that the wiring is complete.

Rat-lines are lines having the special property that they only connect to pins and pads at their end points. Rat-lines are drawn on the screen with a stippled pattern to make them easier to identify since they have special behavior and cannot remain in a completed layout. Rat-lines are added in the minimum length straight-line tree pattern (always ending on pins or pads) that satisfies the missing connectivity in the circuit. Used in connection with moves and rotates of the elements, they are extremely useful for deciding where to place elements on the board. The rat-lines will always automatically rubberband to the elements whether or not the rubberband mode is on. The only way for you to move them is by moving the parts they connect to. This is because it is never desirable to have the rat-lines disconnected from their element pins. Rat-lines will normally criss-cross all over which gives rise to the name "rats nest" describing a layout connected with them. If a SMD pad is unreachable on the active layer, a warning will be issued about it and the rat-line to that pad will not be generated.

A common way to use rats nests is to place some elements on the board, add the rat-lines, and then use a series of moves/rotates of the elements until the rats nest appears to have minimum tangling. You may want to iterate this step several times. Don't worry if the layout looks messy - as long as you can get a sense for whether the criss-crossing is better or worse as you move things, you're fine. After moving some elements around, you may want to optimize the rats nest `<Key>o` so that the lines are drawn between the closest points (this can change once you've moved components). Adding rat-lines only to selected pads/pins (`Shift<Key>w`) is often useful to layout a circuit a little bit at a time. Sometimes you'll want to delete all the rat-lines (`<Key>e`) or selected rat-lines (`Shift<Key>e`) in order to reduce confusion. With a little practice you'll be able to achieve a near optimal component placement with the use of a rats nest.

Rat-lines are not only used for assisting your element placement, they can also help you to route traces on the board. Use the `<Key>m` to convert a rat-line under the cursor into a normal line on the active layer. Inserting a point into a rat-line will also cause the two new lines to be normal lines on the board. Another way that you can use rat-lines is to use the `<Key>f` with the cursor over a pad or pin. All of the pins and pads and rat-lines belonging to that net will be highlighted. This is a helpful way to distinguish one net from the rest of the rats nest. You can then route those tracks, turn off the highlighting (`Shift<Key>f`) and repeat the process. This will work even if the layer that the rat-lines reside on is made invisible - so only the pins and pads are highlighted. Be sure to erase the rat-lines (`<Key>e` erases them all) once you've duplicated their connectivity by adding your own lines. When in doubt, the `<Key>o` will delete only those rat-lines that are no longer needed.

If connections exist on the board that are not listed in the netlist when `<Key>w` is pressed, warning messages are issued and the affected pins and pads are drawn in a special `warnColor` until the next `Notify()` event. If the entire layout agrees completely with the netlist, a message informs you that the layout is complete and no rat-lines will be added (since none are needed). If the layout is complete, but still has rat-lines then you will be warned that rat-lines remain. If you get no message at all it's probably because some elements listed in the net list can't be found and were reported in an earlier message. There shouldn't be any rat-lines left in a completed layout, only normal lines.

The `Shift<Key>w` is used to add rat-lines to only those missing connections among the selected pins and pads. This can be used to add rat-lines in an incremental manner, or to force a rat-line to route between two points that are not the closest points within the net. Often it is best to add the rats nest in an incremental fashion, laying out a sub-section of the board before going further. This is easy to accomplish since new rat-lines are never added where routed connectivity already makes the necessary connections.

3.12 Design Rule Checking

After you've finished laying out a board, you may want to check to be certain that none of your interconnections are too closely spaced or too tenuously touching to be reliably fabricated. The design rule checking (DRC) function does this for you. Use the command `":DRC()"` (without the quotes of course) to invoke the checker. If there are no problem areas, you'll get a message to that effect. If any problem is encountered, you will get a message about it and the affected traces will be highlighted. One part of the tracks of concern will be selected, while the other parts of concern will have the "FindConnection" highlighting. The screen will automatically be centered in the middle of the object having

the "FindConnection" (Green) highlighting. The middle of the object is also the coordinates reported to be "near" the problem. The actual trouble region will be somewhere on the boundary of this object. If the two parts are from different nets then there is some place where they approach each other closer than the minimum rule. If the parts are from the same net, then there is place where they are only barely connected. Find that place and connect them better.

After a DRC error is found and corrected you must run the DRC again because the search for errors is halted as soon as the first problem is found. Unless you've been extremely careless there should be no more than a few design rule errors in your layout. The DRC checker does not check for minimum spacing rules to copper text, so always be very careful when adding copper text to a layout. The rules for the DRC are specified in the application resource file. The minimum spacing value (in mils) is given by the *Settings.Bloat* value. The default is 7 mils. The minimum touching overlap (in mils) is given by the *Settings.Shrink* value. This value defaults to 5 mils. Check with your fabrication process people to determine the values that are right for you.

If you want to turn off the highlighting produced by the DRC, perform an undo (assuming no other changes have been made). To restore the highlighting, use redo. The redo will restore the highlighting quickly without re-running the DRC checker.

3.13 Trace Optimizer

PCB includes a flexible trace optimizer. The trace optimizer can be run after auto routing or hand routing to clean up the traces.

Auto-Optimize

Performs debumpify, unjaggy, orthopull, vianudge, and viatrim, in that order, repeating until no further optimizations are performed.

Debumpify

Looks for U shaped traces that can be shortened or eliminated.

Unjaggy

Looks for corners which could be flipped to eliminate one or more corners (i.e. jaggy lines become simpler).

Vianudge

Looks for vias where all traces leave in the same direction. Tries to move via in that direction to eliminate one of the traces (and thus a corner).

Viatrim

Looks for traces that go from via to via, where moving that trace to a different layer eliminates one or both vias.

Orthopull

Looks for chains of traces all going in one direction, with more traces orthogonal on one side than on the other. Moves the chain in that direction, causing a net reduction in trace length, possibly eliminating traces and/or corners.

SimpleOpts

Removing unneeded vias, replacing two or more trace segments in a row with a single segment. This is usually performed automatically after other optimizations.

Miter

Replaces 90 degree corners with a pair of 45 degree corners, to reduce RF losses and trace length.

3.14 Searching for elements

To locate text or a specific element or grouping of similar elements choose ‘**Select by name**’ from the **Select** menu, then choose the appropriate subsection. At the bottom of the screen the prompt *pattern:* appears. Enter the text or Appendix C [Regular Expressions], page 82 of the text to be found. Found text will be highlighted.

3.15 Measuring distances

To measure distances, for example the pin-to-pin pitch of a part to validate a footprint, place the cursor at the starting measurement point, then press *!Ctrl<Key>m*. This marks the current location with a *X*. The *X* mark is now the zero point origin for the relative cursor position display. The cursor display shows both absolute position and position relative to the mark as the mouse is moved away from the mark. If a mark is already present, the mark is removed and the cursor display stops displaying relative cursor coordinates.

3.16 Vendor Drill Mapping

Pcb includes support for mapping drill holes to a specified set of sizes used by a particular vendor. Many PCB manufacturers have a preferred set of drill sizes and charge extra when others are used. The mapping can be performed on an existing design and can also be enabled to automatically map drill holes as vias and elements are instantiated.

The first step in using the vendor drill mapping feature is to create a resource file describing the capabilities of your vendor. The file format is the resource file format described in Section B.1 [Resource Syntax], page 79. A complete example is given below.

```
# Optional name of the vendor
vendor = "Vendor Name"

# units for dimensions in this file.
# Allowed values:  mil/inch/mm
units = mil

# drill table
drillmap = {
    # When mapping drill sizes, select the nearest size
    # or always round up.  Allowed values:  up/nearest
    round = up

# The list of vendor drill sizes.  Units are as specified
# above.
20
28
35
38
42
52
59.5
86
```

125

152

```

# optional section for skipping mapping of certain elements
# based on reference designator, value, or description
# this is useful for critical parts where you may not
# want to change the drill size. Note that the strings
# are regular expressions.
skips = {
    {refdes "^J3$"} # Skip J3.
    {refdes "J3"} # Skip anything with J3 as part of the refdes.
    {refdes "^U[1-3]$" "^X.*"} # Skip U1, U2, U3, and anything starting with X.
    {value "^JOHNSTECH_.*"} # Skip all Johnstech footprints based on the value of
    {descr "^AMP_MICTOR_767054_1$"} # Skip based on the description.
}
}

# If specified, this section will change the current DRC
# settings for the design. Units are as specified above.
drc = {
    copper_space = 7
    copper_width = 7
    silk_width = 10
    copper_overlap = 4
}

```

The vendor resource is loaded using the *LoadVendor* action. This is invoked by entering:

```
:LoadVendor(vendorfile)
```

from within Pcb. Substitute the file name of your vendor resource file for ‘vendorfile’. This action will load the vendor resource and modify all the drill holes in the design as well as the default via hole size for the various routing styles.

Once a vendor drill map has been loaded, new vias and elements will automatically have their drill hole sizes mapped to the vendor drill table. Automatic drill mapping may be disabled under the “Settings” menu. To re-apply an already loaded vendor drill table to a design, choose “Apply vendor drill mapping” from the “Connects” menu.

See Section 6.2 [Actions], page 45 for a complete description of the actions associated with vendor drill mapping.

Note that the expressions used in the *skips* section are regular expressions. See Appendix C [Regular Expressions], page 82 for an introduction to regular expressions.

4 Commandes Utilisateur

The entering of user-commands is initiated by the action routine *Command()* (the ":" character) and finished by either *<Key>Return* or *<Key>Escape* to confirm or to abort. These two key-bindings cannot be changed from the resource file. The triggering event, normally a key press, is ignored. The input area will replace the bottom statusline. It pops up when *Command()* is called. The arguments of the user-commands are passed to the external commands without modification. See also, the resource *saveInTMP*.

There are simple *usage* dialogs for each command and one for the complete set of commands.

'l [filename]'

Loads a new datafile (layout) and, if confirmed, overwrites any existing unsaved data. The filename and the searchpath (*filePath*) are passed to the command defined by *fileCommand*. If no filename is specified a file select box will popup.

'le [filename]'

Loads an element description into the paste buffer. The filename and the searchpath (*elementPath*) are passed to the command defined by *elementCommand*. If no filename is specified a file select box will popup.

'm [filename]'

Loads an layout file into the paste buffer. The filename and the searchpath (*filePath*) are passed to the command defined by *fileCommand*. If no filename is specified a file select box will popup.

'q[!]'

Quits the program without saving any data (after confirmation). q! doesn't ask for confirmation, it just quits.

's [filename]'

Data and the filename are passed to the command defined by the resource *saveCommand*. It must read the layout data from *stdin*. If no filename is entered, either the last one is used again or, if it is not available, a file select box will pop up.

'rn [filename]'

Reads in a netlist file. If no filename is given a file select box will pop up. The file is read via the command defined by the *RatCommand* resource. The command must send its output to *stdout*.

Netlists are used for generating rat's nests (see Section 3.11 [Rats Nest], page 29) and for verifying the board layout (which is also accomplished by the *Ratsnest* command).

'w[q] [filename]'

These commands have been added for the convenience of vi users and have the same functionality as *s* combined with *q*.

'actionCommand'

Causes the actionCommand to be executed. This allows you to initiate actions for which no bindings exist in the resource file. It can be used to initiate any action with whatever arguments you enter. This makes it possible to do

things that otherwise would be extremely tedious. For example, to change the drilling hole diameter of all vias in the layout to 32 mils, you could select everything using the selection menu, then type `":ChangeDrillSize(SelectedVias, 32)"`. (This will only work provided the via's diameter is sufficiently large to accommodate a 32 mil hole). Another example might be to set the grid to 1 mil by typing `":SetValue(Grid, 1)"`. Note that some actions use the current cursor location, so be sure to place the cursor where you want before entering the command. This is one of my favorite new features in 1.5 and can be a powerful tool. Study the Section 6.2 [Actions], page 45 section to see what actions are available.

5 Command-Line Options

There are several resources which may be set or reset in addition to the standard toolkit command-line options. For a complete list refer to Section 6.1 [Resources], page 39.

The synopsis is:

```
pcb [-option ...] [-toolkit_option ...] [layout-file]
or
pcb -specialoption
```

5.1 Options

‘-alldirections/+alldirections’

Disables or enables line clipping to 45 degree angles. Overwrites the resource *allDirectionLines*.

‘-background file’

Selects a PPM file to be displayed as the board background (for tracing). See *backgroundImage* in Section 6.1 [Resources], page 39 for details.

‘-backup value’

Time between two backups in seconds. Passing zero disables the backup feature. Overwrites the resource *backupInterval*.

‘-c value’ Number of characters per output line. The resource *charactersPerLine* is overwritten.

‘-fontfile filename’

The default set of symbols (font) for a new layout is read from this file. All directories as defined by the resource *fontPath* are scanned for the file. The scan is only performed if the filename doesn’t contain a directory component. The *fontFile* resource is changed.

‘-lelement command-line’

Sets the command to be executed when an element is loaded from a file to the paste buffer. The command may contain %f and %p to pass the requested filename and the searchpath to the command. It must write the data to its standard output. The related resource is *elementCommand*.

‘-lfile command-line’

Sets the command to be executed when a new layout is loaded from a file. The command may contain %f and %p to pass the requested filename and the searchpath to the command. It must write the data to its standard output. The related resource is *fileCommand*.

‘-lfont command-line’

Sets the command to be executed when a font is loaded from a file. The command may contain %f and %p to pass the requested filename and the searchpath to the command. It must write the data to its standard output. The related resource is *fontCommand*.

`'-lg layergroups'`

This option overwrites the resource *layerGroups*. See its description for more information. The value is used for new layouts only.

`'-libname filename'`

The default filename for the library. Overwrites the resource *libraryFilename*.

`'-libpath path'`

The default search path for the the library. Overwrites the resource *libraryPath*.

`'-llib command-line'`

Sets the command to be executed when an element is loaded from the library. The command may contain %f and %p to pass the requested filename and the searchpath to the command. %a is replaces by the three arguments *template*, *value* and *package*. The command must write the data to its standard output. The related resource is *libraryCommand*.

`'-llibcont command-line'`

The command lists the contents of the library. The command may contain %f and %p to pass the library filename and the searchpath to the command. Also refer to Section 7.7 [Library File], page 62 and Section 7.6 [Library Contents File], page 62. The related resource is *libraryContentsCommand*.

`'-loggeometry geometry'`

Determines the geometry of the log window.

`'-pnl value'`

Restricts the displayed length of the name of a pin in the pinout window to the passed value. See also, the resource *pinoutNameLength*.

`'-pz value'`

Sets the zoom factor for the pinout window according to the formula: scale = 1:(2 power value). The related resource is *pinoutZoom*.

`'-reset/+reset'`

If enabled, all connections are reset after each element is scanned. This feature is only used while scanning connections to all elements. See also, *resetAfterElement*.

`'-ring/+ring'`

Overrides the resource *ringBellWhenFinished*. If enabled, the bell sounds when connection searching has finished.

`'-rs string'`

Overrides the resource *routeStyle*. The string defines a colon separated list of route styles. The route styles consist of a comma separated list of name, line thickness, via diameter, and via drill size. e.g. "Fat,50,100,40:Skinny,8,35,20:75Ohm,110,110,20"

`'-s/+s'`

Enables/Disables the saving of the previous commandline. Overrides the *saveLastCommand* resource.

`'-save/+save'`

See the resource description of *saveInTMP* for details.

`'-sfile command-line'`

Sets the command to be executed when an layout file is saved. The command may contain %f which is replaced by the filename. The command must read its data from the standard input. The resource *saveCommand* is overwritten.

`'-script filename'`

Specifies a script file containing PCB actions to be executed upon startup. Overwrites the resource *scriptFilename*.

`'-size <width>x<height>'`

Overrides the resource *size* which determines the maximum size of a layout.

`'-v value'` Sets the volume of the X speaker. The value is passed to `XBell()` and must be in the range -100..100.

5.2 Special Options

There are some special options available in addition to normal command line options. Each of these must be the only option specified on a command line. The available special options are:

`'-copyright'`

Prints out the copyright notice and terminates.

`'-version'`

Prints out the version ID and terminates.

`'-help'`

Prints out the usage message and terminates.

6 X11 Interface

This chapter gives an overview about the additional X11 resources which are defined by `Pcb` as well as the defined action routines.

6.1 Non-Standard X11 Application Resources

In addition to the toolkit resources, `Pcb` defines the following resources:

`'absoluteGrid (boolean)'`

Selects if either the grid is relative to the position where it has changed last or absolute, the default, to the origin (0,0).

`'alignmentDistance (dimension)'`

Specifies the distance between the boards outline to the alignment targets.

`'allDirectionLines (boolean)'`

Enables (default) or disables clipping of new lines to 45 degree angles.

`'backgroundImage (string)'`

If specified, this image will be drawn as the background for the board. The purpose of this option is to allow you to use a scan of an existing layout as a prototype for your new layout. To do this, there are some limitations as to what this image must be. The image must be a PPM binary image (magic number 'P6'). It must have a maximum pixel value of 255 or less (i.e. no 16-bit images). It must represent the entire board, as it will be scaled to fit the board dimensions exactly. Note that it may be scaled unevenly if the image doesn't have the same aspect ratio of your board. You must ensure that the image does not use more colors than are available on your system (mostly this is for pseudo-color displays, like old 8-bit displays). For best results, I suggest the following procedure using The Gimp: Load your image (any type). Image->Scale if needed. Image->Colors->Curves and for each of Red, Green, and Blue channel move the lower left point up to about the 3/4 line (value 192). This will make your image pale so it doesn't interfere with the traces you'll be adding. Image->Mode->Indexed and select, say, 32 colors with Normal F-S dithering. File->Save As, file type by extension, use '.ppm' as the extension. Select Raw formatting.

`'backupInterval (int)'`

`Pcb` has an automatic backup feature which saves the current data every `n` seconds. The default is `300` seconds. A value of zero disables the feature. The backup file is named `'/tmp/PCB.%i.backup'` by default (this may have been changed at compilation time via the `BACKUP_NAME` variable in `'globalconfig.h'`). `%i` is replaced by the process ID. See also, the command-line option `-backup`.

`'Bloat (dimension)'`

Specifies the minimum spacing design rule in mils.

`'charactersPerLine (int)'`

Pcb uses this value to determine the page width when creating lists. *N*, the number of characters per line, defaults to *80*. See also, the command-line option *-c*.

`'connectedColor (color)'`

All pins, vias, lines and rectangles which are selected during a connection search are drawn with this color. The default value is determined by *XtDefaultForeground*.

`'cross hairColor (color)'`

This color is used to draw the cross hair cursor. The color is a result of a *XOR* operation with the contents of the Layout area. The result also depends on the default colormap of the X11 server because only the colormap index is used in the boolean operation and Pcb doesn't create its own colormap. The default setting is *XtDefaultForeground*.

`'elementColor (color)'``'elementSelectedColor (color)'`

The elements package part is drawn in these colors, for normal and selected mode, respectively, which both default to *XtDefaultForeground*.

`'elementCommand (string)'`

Pcb uses a user defined command to read element files. This resources is used to set the command which is executed by the users default shell. Two escape sequences are defined to pass the selected filename (*%f*) and the current search path (*%p*). The command must write the element data to its standard output. The default value is

```
M4PATH="%p";export M4PATH;echo 'include(%f)' | m4
```

Using the GNU version of *m4* is highly recommended. See also, the command-line option *-lelement*.

`'elementPath (string)'`

A colon separated list of directories or commands (starts with '|'). The path is passed to the program specified in *elementCommand* together with the selected element name. A specified command will be executed in order to create entries for the fileselect box. It must write its results to *stdout* one entry per line. See also, the user-command *le[!]*.

`'fileCommand (string)'`

The command is executed by the user's default shell whenever existing layout files are loaded. Data is read from the command's standard output. Two escape sequences may be specified to pass the selected filename (*%f*) and the current search path (*%p*). The default value is:

```
cat %f
```

See also, the command-line option *-lfile*.

`'filePath (string)'`

A colon separated list of directories or commands (starts with '|'). The path is passed to the program specified in *fileCommand* together with the selected

filename. A specified command will be executed in order to create entries for the fileselect box. It must write its results to *stdout* one entry per line. See also, the user-command *l!/?*.

‘fontCommand (string)’

Loading new symbol sets also is handled by an external command. You again may pass the selected filename and the current search path by passing %f and %p in the command string. Data is read from the commands standard output. This command defaults to

```
cat %f
```

See also, the command-line option *-lfont*.

‘fontFile (string)’

The default font for new layouts is read from this file which is searched in the directories as defined by the resource *fontPath*. Searching is only performed if the filename does not contain a directory component. The default filename is ‘default_font’. See also, the command-line option *-fontfile*.

‘fontPath (string)’

This resource, a colon separated list of directories, defines the searchpath for font files. See also, the resource *fontFile*.

‘grid (int)’

This resources defines the initial value of one cursor step. It defaults to *100 mil* and any changes are saved together with the layout data.

‘gridColor (color)’

This color is used to draw the grid. The color is a result of a *INVERT* operation with the contents of the Layout area. The result also depends on the default colormap of the X11 server because only the colormap index is used in the boolean operation and Pcb doesn’t create its own colormap. The default setting is *XtDefaultForeground*.

‘elementColor (color)’

Elements located on the opposite side of the board are drawn in this color. The default is *XtDefaultForeground*.

‘layerColor1..MAX_LAYER (color)’

‘layerSelectedColor1..MAX_LAYER (color)’

These resources define the drawing colors of the different layers in normal and selected state. All values are preset to *XtDefaultForeground*.

‘layerGroups (string)’

The argument to this resource is a colon separated list of comma separated layer numbers (1..MAX_LAYER). All layers within one group are switched on/off together. The default setting is *1:2:3:...:MAX_LAYER* which means all layers are handled separately. Grouping layers one to three looks like *1,2,3:4:...:MAX_LAYER* See also, the command-line option *-lg*.

‘layerName1..MAX_LAYER (string)’

The default name of the layers in a new layout are determined by these resources. The defaults are empty strings.

`'libraryCommand (string)'`

Pcb uses a command to read element data from libraries. The resource is used to set the command which is executed by the users default shell. Three escape sequences are defined to pass the selected filename (%f), the current search path (%p) as well (%a) as the three parameters *template*, *value* and *package* to the command. It must write the element data to its standard output. The default value is

NONE/share/pcb/oldlib/QueryLibrary.sh %p %f %a

`'libraryContentsCommand (string)'`

Similar to *libraryCommand*, Pcb uses the command specified by this resource to list the contents of a library.

NONE/share/pcb/oldlib/ListLibraryContents.sh %p %f

is the default.

`'libraryFilename (string)'`

The resource specifies the name of the library. The default value is *pcbib* unless changed at compile time with the LIBRARYFILENAME variable in 'globalconfig.h'.

`'libraryPath (string)'`

A colon separated list of directories that will be passed to the commands specified by *elementCommand* and *elementContentsCommand*.

`'lineThickness (dimension)'`

The value, in the range [1..250] (the range may be changed at compile time with the MIN_LINESIZE and MAX_LINESIZE variables in 'globalconfig.h'), defines the initial thickness of new lines. The value is preset to *ten mil*.

`'media (<predefined> | <width>x<height>+-<left_margin>+-<top_margin>)'`

The default (user defined) media of the PostScript device. Predefined values are *a3*, *a4*, *a5*, *letter*, *tabloid*, *ledger*, *legal*, and *executive*. The second way is to specify the medias width, height and margins in mil. The resource defaults to *a4* size unless changed at compile time with the DEFAULT_MEDIASIZE variable in 'globalconfig.h'.

`'offLimitColor (color)'`

The area outside the current maximum settings for width and height is drawn with this color. The default value is determined by *XtDefaultBackground*.

`'pinColor (color)'``'pinSelectedColor(color)'`

This resource defines the drawing color of pins and pads in both states. The values are preset to *XtDefaultForeground*.

`'pinoutFont (string)'`

This fonts are used to display pin names. There is one font for each zoom value. The values are preset to *XtdefaultFont*.

`'pinoutNameLength (int)'`

This resource limits the number of characters which are displayed for pin names in the pinout window. By default the string length is limited to *eight* characters per name. See also, the command-line option *-pnl*.

`'pinoutOffsetX (int)'`

`'pinoutOffsetY (int)'`

These resources determine the offset in *mil* of the circuit from the upper left corner of the window when displaying pinout information. Both default to *100 mil*.

`'pinoutTextOffsetX (int)'`

`'pinoutTextOffsetY (int)'`

The resources determine the distance in mil between the drilling hole of a pin to the location where its name is displayed in the pinout window. They default to *X:50* and *Y:0*.

`'pinoutZoom (int)'`

Sets the zoom factor for the pinout window according to the formula: $scale = 1:(2 \text{ power value})$. Its default value is *two* which results in a *1:4* scale. See also, the command-line option *-pz*.

`'printCommand (string)'`

Default file for printouts. If the name starts with a *'|'* the output is piped through the command. A *%f* is replaced by the current filename. There is no default file or command.

`'raiseLogWindow (boolean)'`

The log window will be raised when new messages arrive if this resource is set *true*, the default.

`'ratCommand (string)'`

Default command for reading a netlist. A *%f* is replaced by the netlist filename. Its default value is *"cat %f"*.

`'ratPath (string)'`

Default path to look for netlist files. Its default value is *"."*

`'resetAfterElement (boolean)'`

If set to *true*, all found connections will be reset before a new element is scanned. This will produce long lists when scanning the whole layout for connections. The resource is set to *false* by default. The feature is only used while looking up connections of all elements. See also, the command-line option *-reset*, *+reset*.

`'ringBellWhenFinished (boolean)'`

Whether to ring the bell (the default) when a possibly lengthy operation has finished or not. See also, the command-line option *-ring*, *+ring*.

`'routeStyle (string)'`

Default values for the menu of routing styles (seen in the sizes menu). The string is a comma separated list of name, line thickness, via diameter, and via drill size. e.g. *"Fat,50,100,40:Skinny,8,35,20:75Ohm,110,110,20"* See also, the command-line option *-rs* and *Sizes Menu*

‘rubberBandMode (boolean)’

Whether rubberband move and rotate (attached lines stretch like rubberbands) is enabled (the default).

‘saveCommand (string)’

This command is used to save data to a layout file. The filename may be indicated by placing %f in the string. It must read the data from its standard input. The default command is:

```
cat - > %f
```

See also, the command-line option *-sfile*.

‘saveInTMP (boolean)’

Enabling this resource will save all data which would otherwise be lost in a temporary file *‘/tmp/PCB.%i.save’*. The file name may be changed at compile time with the **EMERGENCY_NAME** variable in *‘globalconfig.h’*. . %i is replaced by the process ID. As an example, loading a new layout when the old one hasn’t been saved would use this resource. See also, the command-line option *-save, +save*.

‘saveLastCommand (boolean)’

Enables the saving of the last entered user command. The option is *disabled* by default. See also, the command-line option *-s, +s*.

‘Shrink (dimension)’

Specifies the minimum overlap (touching) design rule in mils.

‘size (<width>x<height>)’

Defines the width and height of a new layout. The default is *7000x5000* unless changed at compile time with the **DEFAULT_SIZE** variable in *‘globalconfig.h’*.

‘stipplePolygons (boolean)’

Determines whether to display polygons on the screen with a stippled pattern. Stippling can create some amount of transparency so that you can still (to some extent) see layers beneath polygons. It defaults to *False*.

‘textScale (dimension)’

The font scaling in percent is defined by this resource. The default is *100* percent.

‘useLogWindow (boolean)’

Several subroutines send messages to the user if an error occurs. This resource determines if they appear inside the log window or as a separate dialog box. See also, the resource *raiseLogWindow* and the command line option *-loggeometry*. The default value is *true*.

‘viaColor (color)’**‘viaSelectedColor (color)’**

This resource defines the drawing color of vias in both states. The values are preset to *XtDefaultForeground*.

‘viaThickness (dimension)’

‘viaDrillingHole (dimension)’

The initial thickness and drilling hole of new vias. The values must be in the range [30..400] (the range may be changed at compile time with the MIN_PINORVIASIZE and MAX_PINEORVIASIZE variables in ‘globalconfig.h’), with at least 20 mil of copper. The default thickness is *40 mil* and the default drilling hole is *20 mil*.

‘volume (int)’

The value is passed to XBell() which sets the volume of the X speaker. The value lies in the range -100..100 and it defaults to the maximum volume of *100*.

‘warnColor (color)’

This resource defines the color to be used for drawing pins and pads when a warning has been issued about them.

‘zoom (int)’

The initial value for output scaling is set according to the following formula: scale = 1:(2 power value). It defaults to *three* which results in an output scale of *1:8*.

Refer also to Chapter 5 [Command-Line Options], page 36.

6.2 Actions

All user accessible commands may be bound to almost any X event. Almost no default binding for commands is done in the binaries, so it is vital for the application that at least a system-wide application resource file exists. This file normally resides in the ‘share/pcb’ directory and is called ‘Pcb’. The bindings to which the manual refers to are the ones as defined by the shipped resource file. Besides binding an action to an X11 event, you can also execute any action command using a ":" command (see Chapter 4 [Commandes Utilisateur], page 34).

Take special care about translations related to the functions keys and the pointer buttons because most of the window managers use them too. Change the file according to your hardware/software environment. You may have to replace all occurrences of *baseTranslations* to *translations* if you use a X11R4 server.

Passing *Object* as an argument to an action routine causes the object at the cursor location to be changed, removed or whatever. If more than one object is located at the cross hair position the smallest type is used. If there are two of the same type the newer one is taken. *SelectedObjects* will handle all selected and visible objects.

‘AddRats(AllRats|SelectedRats)’

Adds rat-lines to the layout using the loaded netlist file (see the *:rn*, Chapter 4 [Commandes Utilisateur], page 34.). Rat lines are added on the active layer using the current line thickness shown in the status line. Only missing connectivity is added by the AddRats command so if, for example, the layout is complete nothing will be added. Rat lines are drawn on the screen with a stippled pattern to make them easier to identify since they cannot appear in a completed layout. The rat-lines are added in the minimum length straight-line

tree pattern (always ending on pins or pads) that satisfies the missing connectivity in the circuit. If a SMD pad is unreachable on the active layer, a warning will be issued about it and the rat-line to that pad will not be generated. If connections exist on the board which are not listed in the netlist while `AllRats` are being added, warning messages will be issued and the affected pins and pads will be drawn in a special *warnColor* until the next *Notify()* event. If the entire layout agrees completely with the net-list a message informs you that the layout is complete and no rat-lines are added (since none are needed). If *SelectedRats* is passed as the argument, only those missing connections that might connect among the selected pins and pads are drawn. Default:

```
None<Key>w:  AddRats(AllRats)
!Shift<Key>w:  AddRats(SelectedRats)
None<Key>o:  DeleteRats(AllRats) AddRats(AllRats)
!Shift<Key>o:  DeleteRats(SelectedRats) AddRats(SelectedRats)
```

‘ApplyVendor()’

Applies an already loaded vendor drill map to the design.

```
ApplyVendor()
```

‘Atomic(Save|Restore|Block|Close)’

Controls the undo grouping of sequences of actions. Before the first action in a group, `Atomic(Save)` should be issued. After each action that might be undoable, `Atomic(Restore)` should be issued. `Atomic(Block)` concludes and save the undo grouping if there was anything in the group to undo. `Atomic(Close)` concludes and save the undo grouping even if nothing was actually done. Thus it might produce an "empty" undo. This can be useful when you want to use undo in a group of actions.

‘Bell([-100..100])’

Rings the bell of your display. If no value is passed the setting of the resource *volume* will be used.

‘ChangeClearSize(Object, value[, unit])’

‘ChangeClearSize(SelectedPins|SelectedVias, value[, unit])’

The effect of this action depends on if the soldermask display is presently turned on or off. If soldermask is displayed, then the soldermask relief size will be changed. If soldermask display is turned off, then the clearance to polygons will be changed. *unit* is "mil" or "mm". If not specified the units will default to the internal unit of 0.01 mil.

```
!Mod1<Key>k:      ChangeClearSize(Object, +2, mil)
!Mod1 Shift<Key>k: ChangeClearSize(Object, -2, mil)
```

‘ChangeDrillSize(Object, value[, unit])’

‘ChangeDrillSize(SelectedPins|SelectedVias, value[, unit])’

This action routine changes the drilling hole of pins and vias. If *value* starts with + or -, then it adds (or subtracts) *value* from the current hole diameter, otherwise it sets the diameter to the value. *unit* is "mil" or "mm". If not specified the units will default to the internal unit of 0.01 mil. Default:

```
!Mod1<Key>s:      Change2ndSize(Object, +5, mil)
```

```

!Mod1 Shift<Key>s: Change2ndSize(Object, -5, mil)
‘ChangeFlag(Object|SelectElements|SelectedPins|SelectedVias|Selected,thermal|octagon|square)
Sets/clears the indicated flag. This adds/removes thermals, adds/removes the
flag which indicates a pin/pad should be square, or adds/removes the flag which
indicates a pin/pad should be octagonal.
:ChangeFlag(SelectedVias,thermal,1)
:ChangeFlag(SelectedPads,square,0)
‘ChangeHole(Object|SelectedVias)’
This action routine converts a via to and from a hole. A hole is a via that has
no copper annulus. The drill size for the via determines the hole diameter.
!Ctrl<Key>h: ChangeHole(Object)
‘ChangeName(Object)’
‘ChangeName(Layer|Layout)’
Changes the name of the visible object at the cursor location. A text ob-
ject doesn’t have a name therefore the text string itself is changed. The el-
ement name currently used for display is always the one changed with this
command. See Display(Description|NameOnPCB|Value) for details. Passing
Layer changes the current layers name. Default:
None<Key>n: ChangeName(Object)
‘ChangeOctagon(Object|SelectElements|SelectedPins|SelectedVias|Selected)’
Toggles what shape the affected pin(s) or via(s) will be drawn when they are
not square. The shape will either be round or octagonal. Default:
!Ctrl<Key>o: ChangeOctagon(Object)
‘ChangeSize(Object, value[, unit])’
‘ChangeSize(SelectedLines|SelectedPins|SelectedVias, value[, unit])’
‘ChangeSize(SelectedPads|SelectedTexts|SelectedNames, value[, unit])’
‘ChangeSize(SelectedElements, value[, unit])’
To change the size of an object you have to bind these action to some X event (or
use :ChangeSize(...)). If value begins with a + or - then the value will be added
(or subtracted) from the current size, otherwise the size is set equal to value.
Range checking is done to insure that none of the maximum/minimums of any
size are violated. If Object is passed then a single object at the cursor location
is changed. If any of the Selected arguments are passed then all selected and
visible objects of that type are changed. If the type being modified is an element,
then the thickness of the silkscreen lines defining the element is changed. unit
is "mil" or "mm". If not specified the units will default to the internal unit of
0.01 mil. Default:
None<Key>s: ChangeSize(Object, +5)
!Shift<Key>s: ChangeSize(Object, -5)
‘ChangeSquare(Object|SelectedElements|SelectedPins)’
Toggles the setting of the square flag. The flag is used to identify a certain
pin, normally the first one, of circuits. It is also used to make SMD pads have
square ends.

```

```

        None<Key>q:    ChangeSquare(Object)
‘ClrFlag(Object|SelectElements|SelectedPins|SelectedVias|Selected,thermal|octagon|square)’
    Clears the indicated flag. This removes thermals, removes the flag which indi-
    cates a pin/pad should be square, or removes the flag which indicates a pin/pad
    should be octagonal.
        :ClrFlag(SelectedVias,thermal)
‘Command()’
    Calling Command() pops up an input line at the bottom of the window which
    allows you to enter commands. Including all action commands! The dialog ends
    when None<Key>Return to confirm or None<Key>Escape to abort is entered.
    Default:
        <Key>colon: Command()
‘Connection(Find)’
‘Connection(ResetFoundLinesAndRectangles|ResetPinsViasAndPads|Reset)’
    The Connection() action is used to mark all connections from one pin, line or
    via to others. The ResetFoundLinesAndRectangles, ResetFoundPinsAndVias
    and Reset arguments may be used to reset all marked lines and rectangles, vias
    and pins or all of them. The search starts with the pin or via at the cursor
    position. All found objects are drawn with the color defined by the resource
    connectedColor. See also, Display(Description|NameOnPCB|Value). Default:
        !Shift<Key>c: Connection(Reset)
        None<Key>f:    Connection(Find)
        !Shift<Key>f: Connection(Reset)
‘DeleteRats(AllRats|SelectedRats)’
    This routine deletes either all rat-lines in the layout, or only the selected and
    visible ones. Non-rat-lines and other layout objects are unaffected. Default:
        None<Key>e:    DeleteRats(AllRats)
        !Shift<Key>e: DeleteRats(SelectedRats)
‘DisableVendor()’
    Disables automatic drill size mapping to the loaded vendor drill table.
        DisableVendor()
‘DisperseElements(All|Selected)’
    Disperses either all elements or only the selected elements in the layout. This
    action should be used at the start of a design to spread out all footprints before
    any placement or routing is done.
        DisperseElements(All)
‘Display(Description|NameOnPCB|Value)’
‘Display(Toggle45Degree|CycleClip)’
‘Display(Grid|ToggleGrid)’
‘Display(ToggleRubberBandMode)’
‘Display(Center|ClearAndRedraw|Redraw)’
‘Display(Pinout|PinOrPadName)’
    This action routines handles some output related settings. It is used to center
    the display around the cursor location and to redraw the output area optionally

```

after clearing the window. Centering is done with respect to the *grid* setting. Displaying the grid itself may be switched on and off by *Grid* but only if the distance between two pixels exceeds 4 pixels. *Pcb* is able to handle several labels of an element. One of them is a description of the functionality (eg resistor), the second should be a unique identifier (R1) whereas the last one is a value (100k). The *Display()* action selects which of the names is displayed. It also controls which name will be affected by the *ChangeName* command. If *ToggleGrid* is passed, *Pcb* changes between relative ('rel' in the statusline) and absolute grid (an 'abs' in the statusline). Relative grid means the pointer position when the command is issued is used as the grid origin; while (0,0) is used in the absolute grid case. Passing *Pinout* displays the pinout of the element at the current cursor location whereas *PinOrPadName* toggles displaying of the pins or pads name under the cursor. If none of them matches but the cursor is inside of an element, the flags is toggled for all of its pins and pads. For details about rubberbands see also the details about *Mode*. Default:

```
None<Key>c: Display(Center)
None<Key>d: Display(PinOrPadName)
!Shift<Key>d: Display(Pinout)
None<Key>r: Display(ClearAndRedraw)
None<Key>.: Display(Toggle45Degree)
None<Key>/: Display(CycleClip)
```

'DRC()' Initiates design rule checking of the entire layout. Must be repeated until no errors are found.

'ExecuteFile(filename)'

Executes the PCB actions contained in the specified file. This can be used to automate a complex sequence of operations.

```
:ExecuteFile(custom.cmd)
```

The command file contains a list of PCB actions. Blank lines are ignored and lines starting with a # are treated as comment lines. For example

```
# This is a comment line
Display(Grid)
SetValue(Zoom,2)
DRC()
```

'EditLayerGroups()'

Pops up a dialog box to edit the layergroup setting. The function is also available from the *Objects* menu. There are no defaults.

'EnableVendor()'

Enables automatic drill size mapping to the loaded vendor drill table.

```
EnableVendor()
```

'Load(ElementToBuffer|Layout|LayoutToBuffer|Nelist)'

This routine pops up a fileselect box to load layout, element data, or netlist. The passed filename for layout data is saved and may be reused. *ElementToBuffer* and *LayoutToBuffer* load the data into the current buffer. There are no defaults.

‘LoadVendor(vendorfile)’

Loads the specified vendor resource file.

LoadVendor(myvendor.res)

‘MarkCrosshair()’

This routine marks the current cursor location with an X, and then the cursor display shows both absolute position and position relative to the mark. If a mark is already present, this routine removes it and stops displaying relative cursor coordinates. Defaults:

!Ctrl<key>m: MarkCrosshair()

‘Mode(Copy|InsertPoint|Line|Move|None|PasteBuffer|Polygon|Thermal)’

‘Mode(Remove|Rectangle|RubberbandMove|Text|Via)’

‘Mode(Cycle)’

‘Mode(Notify)’

‘Mode(Save|Restore)’

Switches to a new mode of operation. The active mode is displayed by a thick line around the matching mode selector button. Most of the functionality of Pcb is implemented by selecting a mode and calling *Mode(Notify)*. The arguments *Line*, *Polygon*, *Rectangle*, *Text* and *Via* are used to create the appropriate object whenever *Mode(Notify)* is called. Some of them, such as *Polygon*, need more than one call for one object to be created. *InsertPoint* adds points to existing polygons or lines. *Save* and *Restore* are used to temporarily save the mode, switch to another one, call *Mode(Notify)* and restore the saved one. Have a look at the application resource file for examples. *Copy* and *Move* modes are used to change an object’s location and, optionally, to create a new one. The first call of *Mode(Notify)* attaches the object at the pointer location to the cross hair whereas the second one drops it to the layout. The *rubberband* version of move performs the move while overriding the current rubberband mode. Passing *PasteBuffer* attaches the contents of the currently selected buffer to the cross hair. Each call to *Mode(Notify)* pastes this contents to the layout. *Mode(Cycle)* cycles through the modes available in the mode-button pallet. *Mode(None)* switches all modes off. Default:

<Key>Escape:	Mode(None)
<Key>space:	Mode(Cycle)
None<Key>BackSpace:	Mode(Save) Mode(Remove) Mode(Notify) Mode(Restore)
None<Key>Delete:	Mode(Save) Mode(Remove) Mode(Notify) Mode(Restore)
None<Key>F1:	Mode(Via)
None<Key>F2:	Mode(Line)
None<Key>F3:	Mode(PasteBuffer)
None<Key>F4:	Mode(Rectangle)
None<Key>F5:	Mode(Text)
None<Key>F6:	Mode(Polygon)
None<Key>F7:	Mode(Thermal)
None<Key>F8:	Mode(Arc)
None<Key>Insert:	Mode(InsertPoint)
None<Key>[:	Mode(Save) Mode(Move) Mode(Notify)

```

None<Key>]:          Mode(Notify) Mode(Restore)
None<Btn1>:          Mode(Notify)
!Shift Ctrl<Btn1>:  Mode(Save) Mode(Remove) Mode(Notify) Mode(Restore)
None<Btn2Down>:      Mode(Save) Mode(Move) Mode(Notify)
None<Btn2Up>:        Mode(Notify) Mode(Restore)
!Mod1<Btn2Down>:    Mode(Save) Mode(Copy) Mode(Notify)
!Mod1<Btn2Up>:      Mode(Notify) Mode(Restore)
Shift BTNMOD<Btn2Down>: Mode(Save) Mode(RubberbandMove) Mode(Notify)

```

‘MovePointer(delta_x, delta_y)’

With this function it is possible to move the cross hair cursor by using the cursor keys. The X server’s pointer follows because the necessary events are generated by Pcb. All movements are performed with respect to the currently set grid value. Default:

```

None<Key>Up:        MovePointer(0, -1)
!Shift<Key>Up:      MovePointer(0, -10)
None<Key>Down:      MovePointer(0, 1)
!Shift<Key>Down:    MovePointer(0, 10)
None<Key>Right:     MovePointer(1, 0)
!Shift<Key>Right:   MovePointer(10, 0)
None<Key>Left:      MovePointer(-1, 0)
!Shift<Key>Left:    MovePointer(-10, 0)

```

‘MoveToCurrentLayer(Object|SelectedObjects)’

The function moves a single object at the cross hair location or all selected objects to the current layer. Elements are not movable by this function. They have to be deleted and replaced on the other side. If a line segment is moved and the movement would result in a loss of connectivity to another segment then via(s) are automatically added to maintain the connectivity.

```

None<Key>m:          MoveToCurrentLayer(Object)
!Shift<Key>m:        MoveToCurrentLayer(SelectedObjects)

```

‘New()’ Clear the current layout and starts a new one after entering its name. Refer to the resource *backup* for more information. No defaults.

‘PasteBuffer(AddSelected|Clear|1..5)’

‘PasteBuffer(Rotate, 1..3)’

‘PasteBuffer(Convert)’

This action routine controls and selects the pastebuffer as well as all cut-and-paste operations. Passing a buffer number selects one in of the range 1..5. The statusline is updated with the new number. *Rotate* performs a number of 90 degree counter clockwise rotations of the buffer contents. *AddSelected* as first argument copies all selected and visible objects into the buffer. Passing *Clear* removes all objects from the currently selected buffer. *Convert* causes the contents of the buffer (lines, arc, vias) to be converted into an element definition. Refer to Section 3.5.7 [Pastebuffer], page 25 for examples. Default:

```

!Ctrl<Key>x:          PasteBuffer(Clear) PasteBuffer(AddSelected)
                    Mode(PasteBuffer)
!Shift Ctrl<Key>x:   PasteBuffer(Clear) PasteBuffer(AddSelected)

```



```

        RemoveSelected() Mode(PasteBuffer)
!Mod1<Key>c:      PasteBuffer(Clear) PasteBuffer(AddSelected)
!Mod1<key>x:      PasteBuffer(Clear) PasteBuffer(AddSelected)
        RemoveSelected()
!Shift<Key>1:     PasteBuffer(1)
!Shift<Key>2:     PasteBuffer(2)
!Shift<Key>3:     PasteBuffer(3)
!Shift<Key>4:     PasteBuffer(4)
!Shift<Key>5:     PasteBuffer(5)
None<Key>F3:     Mode(PasteBuffer)

```

'Polygon((Close|PreviousPoint)'

Polygons need a special action routine to make life easier. Calling *Polygon(PreviousPoint)* resets the newly entered corner to the previous one. The Undo action will call *Polygon(PreviousPoint)* when appropriate to do so. *Close* creates the final segment of the polygon. This may fail if clipping to 45 degree lines is switched on, in which case a warning is issued. Default:

```

None<Key>p:      Polygon(Close)
!Shift<Key>p:    Polygon(Close)

```

'Print()' Pops up a print control box that lets you select the output device, scaling and many more options. Each run creates all files that are supported by the selected device. These are mask files as well as drilling files, silk screens and so on. The table shows the filenames for all possible files:

POSIX (extension)	8.3 filename
-----	-----
_componentmask.	cmsk.*
_componentsilk.	cslk.*
_soldermask.	smsk.*
_soldersilk.	sslk.*
_drill.	dril.*
_groundplane.	gpl.*
_group[1..8].	[..8].*

The output may be sent to a post-processor by starting the filename with the *pipe* ("|") character. Any "%f" in a command is replaced with the current filename. The function is available from the *file* menu. There are no defaults.

'Quit()' Quits the application after confirming the operation. Default:

```
<Message>WM_PROTOCOLS: Quit()
```

'Redo()' This routine allows you to recover from the last undo command. You might want to do this if you thought that undo was going to revert something other than what it actually did (in case you are confused about which operations are un-doable), or if you have been backing up through a long undo list and over-shoot your stopping point. Any change that is made since the undo in question will trim the redo list. For example if you add ten lines, then undo three of them you could use redo to put them back, but if you move a line on the board before performing the redo, you will lose the ability to "redo" the three "undone" lines. Default:

!Shift<Key>r: Redo()

‘RemoveSelected()’

This routine removes all visible and selected objects. There are no defaults.

‘Report(Object|DrillReport)’

This routine pops up a dialog box describing the various characteristics of an object (or piece of an object such as a pad or pin) in the layout at the cursor position, or a report about all of the drill holes in the layout. There are no defaults.

‘RouteStyle(1|2|3|4)’

This routine copies the sizes corresponding to the numbered route style into the active line thickness, via diameter, and via drill size. Defaults:

!Ctrl<Key>1: RouteStyle(1)

...

!Ctrl<Key>NUM_STYLES: RouteStyle(NUM_STYLES)

The variable NUM_STYLES is set at compile time in ‘globalconfig.h’.

‘Save(Layout|LayoutAs)’

‘Save(AllConnections|AllUnusedPins|ElementConnections)’

Passing *Layout* saves the layout using the file from which it was loaded or, if it is a new layout, calls *Save(LayoutAs)* which queries the user for a filename. The values: *AllConnections*, *AllUnusedPins* and *ElementConnections* start a connection scan and save all connections, all unused pins or the connections of a single element to a file. There are no defaults.

‘Select(All|Block|Connection|ToggleObject)’

‘Select(ElementByName|ObjectByName|PadByName|PinByName)’

‘Select(TextByName|ViaByName)’

Toggles either the selection flag of the object at the cross hair position (*ToggleObject*) or selects all visible objects, all inside a rectangle or all objects which have been found during the last connection scan. The *ByName* functions use a Appendix C [Regular Expressions], page 82 search, always case insensitive, to select the objects. Default:

None<Btn3Down>: Select(ToggleObject)

None<Btn3Down>,None<Btn3Motion>: See resource file - this is complex

‘SetFlag(Object|SelectElements|SelectedPins|SelectedVias|Selected,thermal|octagon|square)’

Sets the indicated flag. This adds thermals, sets the flag which indicates a pin/pad should be square, or sets the flag which indicates a pin/pad should be octagonal.

:SetFlag(Selected,thermal)

‘SetValue(Grid|LineSize|TextScale|ViaDrillingHole|ViaSize|Zoom, value)’

Some internal values may be changed online by this function. The first parameter specifies which data has to be changed. The other one determines if the resource is set to the passed value, if *value* is specified without sign, or increments/decrements if it is specified with a plus or minus sign. The function doesn’t change any existing object only the initial values of new objects. Use the *ChangeSize()* and *ChangeDrillSize()* to change existing objects. Default:

```

None<Key>g:      SetValue(Grid, +5)
!Shift<Key>g:   SetValue(Grid, -5)
None<Key>l:      SetValue(LineStyle, +5)
!Shift<Key>l:   SetValue(LineStyle, -5)
None<Key>t:      SetValue(TextScale, +10)
!Shift<Key>t:   SetValue(TextScale, -10)
None<Key>v:      SetValue(ViaSize, +5)
!Shift<Key>v:   SetValue(ViaSize, -5)
!Mod1<Key>v:    SetValue(ViaDrillingHole, +5)
!Mod1 Shift<Key>v: SetValue(ViaDrillingHole, -5)
None<Key>z:      SetValue(Zoom, -1)
!Shift<Key>z:   SetValue(Zoom, +1)

```

‘SwapSides()’

This routine changes the board side you are viewing. Default:

```
None<Key>Tab:      SwapSides()
```

‘SwitchDrawingLayer(value)’

Makes layer number 1..MAX_LAYER the current one. Default:

```
None<Key>1:      SwitchDrawingLayer(1)
...
None<Key>MAX_LAYER: SwitchDrawingLayer(MAX_LAYER)
```

‘ToggleHideName(Object|SelectedElements)’

Toggles whether the element’s name is displayed or hidden. If it is hidden you won’t see it on the screen and it will not appear on the silk layer when you print the layout.

```
None<Key>h:      ToggleHideName(Object)
!Shift<Key>h:    ToggleHideName(SelectedElements)
```

‘ToggleVendor()’

Toggles automatic drill size mapping to the loaded vendor drill table.

```
ToggleVendor()
```

‘ToggleVisibility(Layer)’

Toggles the visibility of the layer.

```
Mod1<Key>1:      ToggleVisibility(1)
Mod1<Key>2:      ToggleVisibility(2)
Mod1<Key>3:      ToggleVisibility(3)
Mod1<Key>4:      ToggleVisibility(4)
```

‘Undo()’

‘Undo(ClearList)’

The unlimited undo feature of Pcb allows you to recover from most operations that materially affect your work. Calling *Undo()* without any parameter recovers from the last (non-undo) operation. *ClearList* is used to release the allocated memory. *ClearList* is called whenever a new layout is started or loaded. See also *Redo*. Default:

```
None<Key>u:      Undo()
```

```

        !Shift Ctrl<Key>u: Undo(ClearList)
'UnloadVendor()'
    Unloads the loaded vendor drill table.
        UnloadVendor()
'Unselect(All|Block|Connection)'
    Unselects all visible objects, all inside a rectangle or all objects which have been
    found during the last connection scan. Default:
        !Shift <Btn3Down>: Mode(Save) Mode(None) Unselect(Block)
        !Shift <Btn3Up>:   Unselect(Block) Mode(Restore)

```

6.3 Default Translations

This section covers some default translations of key and button events as defined in the shipped default application resource file. Most of them have already been listed in Section 6.2 [Actions], page 45. Pcb makes use of a nice X11 feature; calling several action routines for one event.

```

'None<Key>BackSpace:'
'None<key>Delete:'
'!Shift<Key>BackSpace:'
'!Shift Ctrl<Btn1>:'
    The object at the cursor location is removed by None<Key>BackSpace or Shift
    Ctrl<Btn1> whereas Shift<Key>BackSpace also removes all other objects that
    are fully-connected to the one at the cursor location.

'!Mod1 Ctrl<Key>Left:'
'!Mod1 Ctrl<Key>Right:'
'!Mod1 Ctrl<Key>Up:'
'!Mod1 Ctrl<Key>Down:'
    Scroll one page in one of the four directions.

'None<Key>Left:, !Shift<Key>Left:'
'None<Key>Right:, !Shift<Key>Right:'
'None<Key>Up:, !Shift<Key>Up:'
'None<Key>Down:, !Shift<Key>Down:'
    Move cross hair either one or ten points in grid.

'None<Key>Return:'
    Finished user input, selects the 'default' button of dialogs.

'None<Key>Escape:'
    Mode(Reset), aborts user input, selects the 'abort' button of dialogs or resets
    all modes.

'None<Btn2Down>, Btn2<Motion>, None<Btn2Up>:'
'!Mod1<Btn2Down>, Btn2<Motion>, !Mod1<Btn2Up>:'
    The first sequence moves the object or element name at the cursor location.
    The second one copies the objects. Copying isn't available for element names.

```

7 File Formats

All files used by Pcb are read from the standard output of a command or written to the standard input of one as plain seven bit ASCII. This makes it possible to use any editor to change the contents of a layout file. It is the only way for element or font description files to be created. To do so you'll need to study the example files 'example/*' and 'default_font' which are shipped with Pcb. For an overview refer to Chapter 2 [Intro], page 5.

The following sections provide the necessary information about the syntax of the files. Netlist files are not created by Pcb, but it does use them. For information on the format of a netlist file see the *:rn*, Chapter 4 [Commandes Utilisateur], page 34. Rat lines are added on the current layer using the current The commands described allow you to add almost any additional functionality you may need. Examples are compressed read and write access as well as archives. The commands themselves are defined by the resources *elementCommand*, *fileCommand*, *fontCommand*, *libraryCommand*, *libraryContentsCommand* and *saveCommand*. Note that the commands are not saved along with the data. It is considered an advantage to have the layout file contain all necessary information, independent of any other files.

One thing common to all files is they may include comments, newlines, and carriage returns at any place except within quoted strings.

7.1 Basic Types

Here are the basic type definitions used in the other sections of this chapter.

Description	= Name
DeltaAngle	= Number
DrillingHole	= Number
Flags	= Number
FontPosition	= Number
Grid	= Number
GridOffsetX	= Number
GridOffsetY	= Number
Group	= GroupMember [,GroupMember]...
GroupMember	= decimal [cs]
GroupString	= "" Group [:Group]... ""
StyleString	= "" Style [:Style]... ""
Height	= Number
LayerNumber	= Number
LayoutName	= Name
Name	= quoted_string
Number	= decimal hex
PinNumber	= quoted_string
Spacing	= Number
StartAngle	= Number
SymbolID	= Number charconst
Thickness	= Number
TextData	= quoted_string
TextFlags	= Flags

```

TextScale      = scale
TextX          = Number
TextY          = Number
Value         = Name
Width         = Number
X             = Number
X1            = Number
X2            = Number
Y             = Number
Y1            = Number
Y2            = Number
charconst     = "'" <any character> "'"
comment       = "#" {<any character up to a newline>}...
decimal       = [0-9]+
direction     = [0-3]
hex           = 0x[0-9a-fA-F]+
scale         = [1-<positive integer>]
quoted_string = "\"" <anything except \n and \r> "\""
zoom          = [0-MAX]

```

7.2 Layout File Format

The layout file describes a complete layout including symbols, vias, elements and layers with lines, rectangles and text. This is the most complex file of all.

```

File          = Header Font PCBData
Header        = PCBName [GridData] [CursorData] [PCBFlags] [Groups]
PCBName       = "PCB(" Name Width Height ")"
GridData      = "Grid(" Grid GridOffsetX GridOffsetY ")"
CursorData    = "Cursor(" X Y zoom ")"
PCBFlags      = "Flags(" Flags ")"
Groups        = "Groups(" GroupString ")"
Styles = "Styles(" StyleString ")"
Font          = {FontData}...
FontData      = {Symbol}...
Symbol        = "Symbol(" SymbolID Spacing ")"
              "(" {SymbolData}... ")"
SymbolData    = {SymbolLine}...
SymbolLine    = "SymbolLine(" X1 Y1 X2 Y2 Thickness ")"
PCBData       = {Via | Layer | Element}...

Via           = "Via(" X Y Thickness DrillingHole Name Flags ")"

Element       = "Element(" Flags Description LayoutName Value \
                TextX TextY direction scale TextFlags)"
              "(" {ElementData}... [Mark] ")"
ElementData   = {ElementLine | Pad | Pin | ElementArc }...
ElementArc    = "ElementArc(" X Y Width Height

```

```

        StartAngle DeltaAngle Thickness ")
ElementLine      = "ElementLine(" X1 Y1 X2 Y2 Thickness ")
Mark             = "Mark(" X Y ")
Pad             = "Pad(" X1 Y1 X2 Y2 Thickness Name PinNumber Flags)"
Pin            = "Pin(" X Y Thickness DrillingHole Name PinNumber Flags ")"

Layer           = "Layer(" LayerNumber Name ")"
                "(" {LayerData}... ")"
LayerData       = {Line | Polygon | Text}...
Line            = "Line(" X1 Y1 X2 Y2 Thickness Flags)"
Arc = "Arc(" X Y Width Height StartAngle DeltaAngle Thickness Flags)"
Polygon         = "Polygon(" Flags ")" \
                "(" {Points}... ")"
Points          = "(" X Y ")"
Text           = "Text(" X Y direction scale TextData Flags)"

```

‘PCBName’ is used to define the layout’s name which is independent of its filename. It is displayed in the lower left corner of the main window.

‘GridData’ is optional and is used to save the grid setting and offset which were set at the time the layout was saved.

‘CursorData’ also is an optional parameter to save the last cursor location and zoom value. The real zoom factor is calculated by $scale = 1:(2 \text{ power value})$.

‘PCBFlags’ determine how to draw lines and which name of the elements should be displayed.

```

        bit 4: do rubberband moves and rotates if set
        bit 5: display description of elements if set
        bit 6: display unique name of an element if set
        bit 7: use absolute grid if set
        bit 8: don't clip lines to 45 degrees

```

‘Groups’ Layergroups are saved by using this optional parameter. The only way of changing them is to use an editor and alter the appropriate line. The characters *c,s* identify the component- and solder-side for SMD objects.

‘Symbol’ See the description of font files in this chapter.

‘Via’ Vias are always connected to all layers which also means vias are one logical level ahead of layers. Vias are defined by position, size, name and by some flags.

```

        bit 0: always clear
        bit 1: always set
        bit 2: set if via was found during a connection search
        bit 4: set if via is a hole (has no copper annulus)
        bit 5: display the vias name

```

```

bit 6: via has been selected
bit 12: set if via has octagonal shape
Other bits have special meaning and should not be changed
by the user. See const.h for more information

```

‘Element’ See the description of element files in this chapter.

‘Layer’ A layer is the central object from the user’s point of view. It holds all connections and all text objects. Up to 8 may be used individually. Its number, starting with one, and its name are read as arguments.

‘Line’ All lines are identified by their start and endpoints together with their thickness and some flags. They have to fit a 45 degree scheme.

```

bit 2: set if line was found during a connection search
bit 4: line is a rat-line
bit 6: line has been selected

```

‘Polygon’ used to fill a larger area with ‘copper’. The coordinates specify the corners. The flags are:

```

bit 2: set if polygon was found during a connection search
bit 4: polygon is a 1.5 style polygon that automatically c
bit 6: polygon has been selected

```

‘Text’ You may use text objects to add information to your board. An example would be naming a connector or marking pin one of it. The position marks the lower left corner of the string which is also a fix-point for rotations. Text directions are independent to those of lines. They are counted from zero to three with a meaning of zero to 270 degree rotations counter-clockwise. The scaling value is a positive integer which determines a zoom factor in percent.

```

bit 6: the text has been selected
bit 7: the text is on the solder (back) side of the board
bit 10: the text is on the silkscreen layer

```

7.3 Element File Format

Element files are used to describe one component which then may be used several times within one or more layouts. You will normally split the file into two parts, one for the pinout and one for the package description. Using `m4` allows you to define pin names as macros in one file and include a package description file which evaluates the macros. See the resource *elementCommand* for more information. The pins (and pads) must appear in sequential order in the element file (new in 1.5) so that pin 1 must be the first PIN(...) in the file.

Doing things this way makes it possible to use one package file for several different circuits. See the sample files ‘dil*’.

The lowest x and y coordinates of all sub-objects of an element are used as an attachment point for the cross hair cursor of the main window.

```

File           = {Element}...
Element       = "Element(" Flags Description LayoutName Value \

```



```

    TextX TextY direction scale TextFlags)"
    "(" {ElementData}... [Mark] ")"
ElementData    = {ElementLine | Pad | Pin | ElementArc }...
ElementArc     = "ElementArc(" X Y Width Height
                StartAngle DeltaAngle Thickness ")"
ElementLine    = "ElementLine(" X1 Y1 X2 Y2 Thickness ")"
Mark           = "Mark(" X Y ")"
Pad            = "Pad(" X1 Y1 X2 Y2 Thickness Name PinNumber Flags ")"
Pin            = "Pin(" X Y Thickness DrillingHole Name PinNumber Flags ")"

```

‘Element’ Objects of type element are determined by flags, some names, a canonical and a layout name as well as a value. Additional fields are text position, their direction counted from zero to three ($n * 90$ degrees counter-clockwise) and element data.

‘Flags’ The flag field determines the state of an element. The bit values are:

- bit 4: the element name is hidden
- bit 6: element has been selected
- bit 7: element is located on the solder side

‘TextFlags’

‘scale’

‘direction’

See the description of text object earlier in this chapter.

‘ElementLine’

A line is defined by its start and end points and by its size, or width.

‘ElementArc’

Defines an arc by its center, width, height, start angle, its length in degrees and its size. Remember the y axis on the screen grows downwards.

‘Mark’ is just a hint to make positioning easier. The cross hair will be positioned here. Its center is passed as the two arguments.

‘Pad’ A pad is very similar to a line except it may not be disconnected from its element and it has an associated name. Is is defined by two end point position, size, name and by some flags.

- bit 2: set if pad was found during a connection search
- bit 5: display the pads name
- bit 6: pad has been selected
- bit 7: pad is located on the solder side

‘Pin’ A pin is very similar to a via except it may not be disconnected from its element.

- bit 0: always set
- bit 1: always clear
- bit 2: set if pin was found during a connection search

bit 3: set if pin is only a mounting hole (no copper annul
bit 5: display the pins name
bit 6: pin has been selected
bit 8: pin is drawn as a square
bit 12: set if pin is drawn with an octagonal shape

7.4 Font File Format

A number of user defined symbols are called a font. There is only one per layout. All symbols are made of lines. See the file 'default_font' as an example.

The lowest x and y coordinates of all lines of a font are transformed to (0,0).

```
File           = Font
Font           = {FontData}...
FontData       = {Symbol}...
Symbol         = "Symbol(" SymbolID FontPosition ")"
               "(" {SymbolData}... ")"
SymbolData     = {SymbolLine}...
```

'Symbol' The two arguments are the ASCII code of the symbol and its distance to the next symbol. Undefined symbols are drawn as filled rectangles. The ASCII code may be passed as a character constant or as a hexadecimal value.

'SymbolLine'
The symbol data itself is made up of several entries of type *SymbolLine*.

7.5 Netlist File Format

Netlists read by Pcb must have this simple text form:

```
netname [style] NAME-PINNUM NAME2-PINNUM2 NAME3-PINNUM3 ... [\]
```

for each net on the layout.

where "netname" is the name of the net which must be unique for each net, [style] is an optional route-style name, NAME is the layout-name name given to an element, and PINNUM is the (usually numeric) pin number of the element that connects to the net (for details on pin numbering see (undefined) [Element Objects], page (undefined)). Spaces or tabs separate the fields. If the line ends with a "\" the net continues on the next line and the "\" is treated exactly as if it were a space. If a NAME ends with a lower-case letter, all lower-case letters are stripped from the end of the NAME to determine the matching layout-name name. For example:

```
Data U1-3 U2abc-4 FLOP1a-7 Uabc3-A9
```

specifies that the net called "Data" should have pin 3 of U1 connected to pin 4 of U2, to pin 7 of FLOP1 and to pin A9 of Uabc3. Note that element name and pin number strings are case-sensitive. It is up to you to name the elements so that their layout-name names agrees with the netlist.

7.6 Library Contents File Format

There is nothing like a special library format. The ones that have been introduced in 1.4.1 just use some nice (and time consuming) features of GNU m4. The only predefined format is the one of the contents file which is read during startup. It is made up of two basic line types:

```

menu entry      = "TYPE="name
contents line   = template":"package":"value":"description
name           = String
template       = String
package        = String
value          = String
description     = String
String         = <anything except ":", "\n" and "\r">

```

No leading white spaces or comments are allowed in this file. If you need either one, define a command that removes them before loading. Have a look to the *libraryContentsCommand* resource.

The menu entry will appear in the selection menu at the top and of the library window.

7.7 Library File Format

This section provides an overview about the existing m4 definitions of the elements. There are basically two different types of files. One to define element specific data like the pinout, package and so on, the other to define the values. For example the static RAM circuits 43256 and 62256 are very similar. They therefore share a common definition in the macro file but are defined with two different value labels.

The macro file entry:

```

define('Description_43256_dil', 'SRAM 32Kx8')
define('Param1_43256_dil', 28)
define('Param2_43256_dil', 600)
define('PinList_43256_dil', 'pin1', 'pin2', ...)

```

And the list file:

```
43256_dil:N:43256:62256
```

The macro must define a description, the pin list and up to two additional parameters that are passed to the package definitions. The first one is the number of pins whereas the second one defines for example the width of a package.

It is very important to select a unique identifier for each macro. In the example this would be *43256_dil* which is also the templates name. It is required by some low-level macros that *Description_*, *Param1_*, *Param2_* and *PinList_* are prepended.

The list file uses a syntax:

```
template:package:value[:more values]
```

This means that the shown example will create two element entries with the same package and pinout but with different names.

A number of packages are defined in 'common.m4'. Included are:

DIL packages with suffix D, DW, J, JD, JG, N, NT, P
PLCC
T03
generic connectors
DIN 41.612 connectors
zick-zack (SD suffix)
15 pin multiwatt

If you are going to start your own library please take care about m4 functions. Be aware of quoting and so on and, most important check your additional entry by calling the macro:

```
CreateObject('template', 'value', 'package suffix')
```

If quoting is incorrect an endless loop may occur (broken by a out-of-memory message).

The scripts in the 'lib' directory handle the creation of libraries as well as of their contents files. Querying is also supported.

I know quite well that this description of the library implementation is not what some out there expect. But in my opinion it's much more useful to look at the comments and follow the macros step by step.

8 Library Creation

This chapter provides a detailed look at how footprint libraries are created and used. The chapter is split into two sections, the first section covers the "old" style libraries which use the `m4` macro processor and the second section covers the "new" style libraries.

Despite the names "old" and "new", both styles of libraries are useful and the "old" style should not be discounted because of its name. The advantage of the old style libraries is that one can define a family of footprints, say a DIP package, and then quickly produce all the members of that family. Because the individual packages make use of a base definition, corrections made to the base definition propagate to all the members of a family. The primary drawback to using this library approach is that the effort to create a single footprint is more than a graphical interface and may take even longer if the user has not used the `m4` macro language previously.

The new style of footprint libraries stores each footprint in its own file. The footprints are created graphically by placing pads and then converting a group of pads to a component. This library method has the advantage of being quick to learn and it is easy to build single footprints quickly. If you are building a family of parts, however, the additional effort in creating each one individually makes this approach undesirable. In addition, creating a part with a large pin count can be quite tedious when done by hand.

8.1 Old Style (`m4`) Libraries

The old style libraries for `pcb` use the `m4` macro processor to allow the definition of a family of parts. There are several files associated with the old style library. The file `'common.m4'` is the top level file associated with the library. `'common.m4'` defines a few utility macros which are used by other portions of the library, and then includes a predefined set of library files (the lines like `include(geda.inc)`).

8.1.1 Overview of Oldlib Operation

The big picture view of the old style library system is that the library is simply a collection of macro definitions. The macros are written in the `m4` macro language. An example of a macro and what it expands to is the following. One of the predefined footprints in the library which comes with `PCB` is the `PKG_S08` macro. Note that all the footprint macros begin with `PKG_`. For this particular example, `PKG_S08` is a macro for an 8-pin small outline surface mount package. All of the footprint macros take 3 arguments. The first is the canonical name of the footprint on the board. In this case "S08" is an appropriate name. The second argument is the reference designator on the board such as "U1" or "U23". The third and final argument is the value. For an integrated circuit this is usually the part number such as "MAX4107" or "78L05" and for a component such as a resistor or capacitor it is the resistance or capacitance. The complete call to the macro in our example is `'PKG_S08(S08, U1, MAX4107)'`. When processed by `m4` using the macros defined in the `PCB` library, this macro expands to

```
Element(0x00 "S08" "U1" "MAX4107" 146 50 3 100 0x00)
(
  Pad(10 25 38 25 20 "1" 0x00)
  Pad(10 75 38 75 20 "2" 0x100)
```

```

Pad(10 125 38 125 20 "3" 0x100)
Pad(10 175 38 175 20 "4" 0x100)
Pad(214 175 242 175 20 "5" 0x100)
Pad(214 125 242 125 20 "6" 0x100)
Pad(214 75 242 75 20 "7" 0x100)
Pad(214 25 242 25 20 "8" 0x100)
ElementLine(0 0 151 0 10)
ElementArc(126 0 25 25 0 180 10)
ElementLine(101 0 252 0 10)
ElementLine(252 0 252 200 10)
ElementLine(252 200 0 200 10)
ElementLine(0 200 0 0 10)
Mark(29 25)
)

```

which is the actual definition of the footprint that the PCB program works with. As a user of PCB the only time you will need or want to run `m4` directly is when you are debugging a new library addition. In normal operation, the calls to `m4` are made by helper scripts that come with PCB.

Tools such as `gsch2pcb` (used to interface the gEDA schematic capture program to PCB layout) will call `m4` to produce an initial PCB layout that includes all the components on a schematic. In addition, when manually instantiating parts from within PCB, `m4` will be called by PCB's helper scripts to produce the footprints.

8.1.2 The Library Scripts

There are several scripts that are used for processing the `m4` libraries. This section briefly describes these scripts and details how they are used by PCB.

8.1.2.1 Scripts Used During Compilation

The scripts described in this section are used during compilation of PCB. They are run automatically by the build system, but are described here to help document the complete library processing that occurs. During the build of PCB, the following actions are taken. The `CreateLibrary.sh` script is run to produce an M4 "frozen file". This frozen file is simply a partially processed M4 input file which can be loaded by M4 more quickly than the original input file.

A typical call to `CreateLibrary.sh` used during the compilation of PCB is:

```

./CreateLibrary.sh -I . pcblib ./common.m4 TTL_74xx_DIL.m4
connector.m4 crystal.m4 generic.m4 genericst.m4 gtag.m4
jerry.m4 linear.m4 logic.m4 lsi.m4 memory.m4 optical.m4 pci.m4
resistor_0.25W.m4 resistor_adjust.m4 resistor_array.m4
texas_inst_amplifier.m4 texas_inst_voltage_reg.m4
transistor.m4 geda.m4

```

The `'-I .'` says to search in the current directory for the `'m4'` files. The output frozen file is `'pcblib'`. The main `'common.m4'` file is listed as well as all of the `'*.m4'` files which define the components in the library.

In addition, a library contents file is created during the build with the `CreateLibraryContents.sh` script. A typical call to `CreateLibrary.sh` used during the compilation of PCB is:

```
./CreateLibraryContents.sh -I . ./common.m4 TTL_74xx_DIL.list
connector.list crystal.list generic.list genericsmt.list gtag.list
jerry.list linear.list logic.list lsi.list memory.list optical.list
pci.list resistor_0.25W.list resistor_adjust.list resistor_array.list
texas_inst_amplifier.list texas_inst_voltage_reg.list transistor.list
geda.list > pcplib.contents
```

The `'pcplib.contents'` file is used by the PCB program to define the libraries and components which will be displayed when you bring up the library window from within PCB. An example of part of the `'pcplib.contents'` file is:

```
TYPE=~TTL 74xx DIL
7400_dil:N:7400:4 dual-NAND
7401_dil:N:7401:4 dual-NAND OC
7402_dil:N:7402:4 dual-NOR
TYPE=~geda
geda_DIP6:DIP6:DIP6: Dual in-line package, narrow (300 mil)
geda_DIP8:DIP8:DIP8: Dual in-line package, narrow (300 mil)
geda_DIP14:DIP14:DIP14: Dual in-line package, narrow (300 mil)
geda_ACY300:ACY300:ACY300: Axial non-polar component,
```

The `TYPE=` lines define the library name that will show up in the library window in PCB. The other lines define the actual components in the library.

8.1.2.2 Scripts Used by PCB at Runtime

When PCB is first executed, it makes a call to the `ListLibraryContents.sh` script. This script provides the PCB program with the contents of the library contents file created when PCB was compiled. A typical call to `ListLibraryContents.sh` is

```
../lib/ListLibraryContents.sh ../tmp/pcb-20030903/src/./lib pcplib
```

This command says to search the path `'../tmp/pcb-20030903/src/./lib'` for a file called `'pcplib.contents'` (the `'contents'` part is added automatically) and display the contents of the file. PCB parses this output and generates the library window entries.

When you pick a library component from the library window, PCB calls the `QueryLibrary.sh` script to actually pull the footprint into the layout. For example, when the ACY300 component is selected from the `~geda` library, the generated call may be:

```
/tmp/pcb-20030903/src/./lib/QueryLibrary.sh
../tmp/pcb-20030903/src/./lib pcplib geda_ACY300 ACY300
ACY300
```

If you were to run this command by hand you would see the PCB code for the element:

```
Element(0x00 "Axial non-polar component," "" "ACY300" 245 70 0 100 0x00)
(
Pin(0 25 50 20 "1" 0x101)
Pin(300 25 50 20 "2" 0x01)
```

```

ElementLine(0 25 75 25 10)
ElementLine(225 25 300 25 10)

ElementLine(75 0 225 0 10)
ElementLine(225 0 225 50 10)
ElementLine(225 50 75 50 10)
ElementLine(75 50 75 0 10)

#      ElementArc(X1 Y 50 50 270 180 10)
#      ElementArc(X2 Y 50 50 90 180 10)

Mark(75 25)
)

```

8.1.3 Creating an Oldlib Footprint

This section provides a complete example of defining a family of footprints using the M4 style library. As a vehicle for this example, a family of footprints for surface mount resistors and capacitors will be developed. The file 'example.inc' should have been installed on your system as '\$prefix/share/examples/oldlib/example.inc' where '\$prefix' is often times '/usr/local'.

The 'example.inc' file defines a macro called COMMON_PKG_RCSMT which is a generic definition for a surface mount footprint with two identical, rectangular pads. This macro will be called with different parameters to fill out the family of parts. The arguments to the COMMON_PKG_RCSMT are:

```

# -----
# the definition for surface mount resistors and capacitors
# $1: canonical name
# $2: name on PCB
# $3: value
# $4: pad width (in direction perpendicular to part)
# $5: pad length (in direction parallel with part)
# $6: pad spacing (center to center)
# $7: distance from edge of pad to silk (in direction
# perpendicular to part)
# $8: distance from edge of pad to silk (in direction parallel
# with part)
# $9: Set to "no" to skip silk screen on the sides of the part
define('COMMON_PKG_RCSMT',
  'define('XMIN', 'eval( -1*'$6'/2 - '$5'/2 - '$8'))'
  define('XMAX', 'eval( '$6'/2 + '$5'/2 + '$8'))'
  define('YMIN', 'eval(-1*'$4'/2 - '$7'))'
  define('YMAX', 'eval( '$4'/2 + '$7'))'
  Element(0x00 "$1" "$2" "$3" eval(XMIN+20) eval(YMAX+20) 0 100 0x00)
  (
  ifelse(0, eval($4>$5),
  # Pads which have the perpendicular pad dimension less

```



```

# than or equal to the parallel pad dimension
Pad(eval(-1*( $6 + $5 - $4)/2) 0
      eval((-1*$6 + $5 - $4)/2) 0 eval($4) "1" 0x100)
Pad(eval(-1*(-1*$6 + $5 - $4)/2) 0
      eval(( $6 + $5 - $4)/2) 0 eval($4) "2" 0x100)
,
# Pads which have the perpendicular pad dimension greater
# than or equal to the parallel pad dimension
Pad(eval(-1*$6/2) eval(-1*($4 - $5)/2)
      eval(-1*$6/2) eval(($4 - $5)/2) eval($5) "1" 0x100)
Pad(eval( $6/2) eval(-1*($4 - $5)/2)
      eval( $6/2) eval(($4 - $5)/2) eval($5) "2" 0x100)
)

# silk screen
# ends
ElementLine(XMIN YMIN XMIN YMAX 10)
ElementLine(XMAX YMAX XMAX YMIN 10)
# sides
ifelse($9,"no",
#skip side silk
,
ElementLine(XMIN YMIN XMAX YMIN 10)
ElementLine(XMAX YMAX XMIN YMAX 10)
)
Mark(0 0)
)')

```

Note that the part has been defined with the mark located at (0,0) and that the pads have been placed with the mark at the common centroid of the footprint. While not a requirement, this is highly desirable when developing a library that will need to interface with a pick and place machine used for factory assembly of a board.

The final part of 'example.inc' defines particular versions of the generic footprint we have created. These particular versions correspond to various industry standard package sizes.

```

# 0402 package
#
# 30x30 mil pad, 15 mil metal-metal spacing=>
# 15 + 15 + 15 = 45 center-to-center
define('PKG_RC0402',
      'COMMON_PKG_RCSMT('$1', '$2', '$3', 30, 30, 45, 0, 10, "no")')

# 0603 package
#
# 40x40 mil pad, 30 mil metal-metal spacing=>
# 30 + 20 + 20 = 70 center-to-center
define('PKG_RC0603',

```

```

COMMON_PKG_RCSMT('$1', '$2', '$3', 40, 40, 70, 10, 10)')

# 1206 package
#
# 40x60 mil pad, 90 mil metal-metal spacing=>
# 90 + 20 + 20 = 130 center-to-center
define('PKG_RC1206',
COMMON_PKG_RCSMT('$1', '$2', '$3', 60, 40, 130, 10, 10)')

```

At this point, the 'example.inc' file could be used by third party tools such as gsch2pcb. However to fully integrate our footprints into PCB we need to create the 'example.m4' and 'example.list' files. The 'example.m4' file defines descriptions for the new footprints.

```

define('Description_my_RC0402',
'Standard SMT resistor/capacitor (0402)')
define('Description_my_RC0603',
'Standard SMT resistor/capacitor (0603)')
define('Description_my_RC1206',
'Standard SMT resistor/capacitor (1206)')

```

Finally we need to create the 'example.list' file.

```

my_RC0402:RC0402:RES0402
my_RC0402:RC0402:CAP0402
my_RC0603:RC0603:RES0603
my_RC0603:RC0603:CAP0603
my_RC1206:RC1206:RES1206
my_RC1206:RC1206:CAP1206

```

The first field in the list file has the name corresponding to the Description definitions in 'example.m4'. The second field is the template name which corresponds to the macros PKG_* we defined in 'example.inc' with the leading PKG_ removed. It is the second field which controls what footprint will actually appear on the board. The final field is the name of the part type on the board. The first line in our 'example.list' file will produce a menu entry in the library window that reads:

```

CAP0402, Standard SMT resistor/capacitor (0402)

```

The CAP0402 portion comes directly from the third field in example.list and the longer description comes from descriptions macros in example.m4. Please note that any extra white space at the end of a line in the '.list' files will cause them to not work properly.

8.1.4 Troubleshooting Old Style Libraries

A powerful technique to help debug problems with libraries is to invoke the m4 processor directly. This approach will provide error output which is not visible from within PCB. The following example shows how one might try to debug an 8 pin small outline (SO8) package. The macro name for the package is PKG_SO8. In this example, the canonical name that is to be associated with the part is SO8, the reference designator is U1, and the value is MAX4107 (the part number).

```

echo "PKG_SO8(SO8, U1, MAX4107)" | \
gm4 common.m4 - | \
awk '/^[ \t]*$/ {next} {print}' | \

```

more

The `awk` call simply removes blank lines which make the output hard to read.

For this particular example, the output is:

```
Element(0x00 "S08" "U1" "MAX4107" 146 50 3 100 0x00)
(
  Pad(10 25 38 25 20 "1" 0x00)
  Pad(10 75 38 75 20 "2" 0x100)
  Pad(10 125 38 125 20 "3" 0x100)
  Pad(10 175 38 175 20 "4" 0x100)
  Pad(214 175 242 175 20 "5" 0x100)
  Pad(214 125 242 125 20 "6" 0x100)
  Pad(214 75 242 75 20 "7" 0x100)
  Pad(214 25 242 25 20 "8" 0x100)
  ElementLine(0 0 151 0 10)
  ElementArc(126 0 25 25 0 180 10)
  ElementLine(101 0 252 0 10)
  ElementLine(252 0 252 200 10)
  ElementLine(252 200 0 200 10)
  ElementLine(0 200 0 0 10)
  Mark(29 25)
)
```

8.2 New Style Libraries

Footprints for the new style library are created graphically using the PCB program. A single footprint is saved in each file.

8.2.1 Creating Newlib Footprints

To create

1. Start PCB with an empty layout.
2. Make the component layer active.
3. For a leaded part, select the via tool and place vias where the pads for the part should go. For surface mount pads, draw line segments. Note that until the footprint is completed, the surface mount pads will remain rounded. Currently a rectangle or polygon may not be used as a pad.
4. For each via and line segment which will become a pad, select it, right-click to bring up the popup menu and choose "edit name". Enter the pin number and press enter. Alternatively, you can use the "n" hotkey to activate the rename command.
5. Make the silk layer active.
6. Using the line and arc tools, draw a silk screen outline for the part.
7. Using the selection tool, select all of the pins and silk screen for the part.
8. Place the pointer above the reference point for the part. This is typically the common centroid. Keeping the pointer there, right-click to bring up the popup menu and choose "convert selection to element".

9. At this point, the vias, line segments, and silk screen will have been converted to an element. To change any of the line segments to have square ends rather than round ends, select the pads by holding down the shift key and clicking each pad with the center mouse button. Now under the Select menu, "Change square-flag of selected objects" section, choose "Pins".
10. Select the element, right-click to bring up the popup menu, and choose "Copy Selection to Buffer". Now left-click on the center of the new element.
11. Under the buffer menu, choose "save buffer elements to file" to save the new footprint to a file.
12. Press ESC to exit from buffer mode.

8.2.2 Modifying Newlib Footprints

1. In the Pcb program, instantiate the footprint you wish to modify.
2. Using the selection tool, select the footprint.
3. Now left-click on the selected element, this brings up a popup menu, choose "Cut Selection to Buffer" from the popup menu.
4. Under the buffer menu, choose "break buffer element to pieces", and then left-click to place the broken apart footprint to an open area of the layout. Note that you must use the items under the buffer menu, the items with the same names in the popup menu do not work.
5. Make your desired modifications to the footprint and then convert the pieces back to an element using the same procedure as when starting from scratch on a new footprint.

9 Capture de schémas pour PCB

Lors de la conception d'un circuit imprimé, quelque soit sa complexité, une interface de capture de schémas pour la conception est fortement souhaitable. Tout programme de capture de schémas qui peut générer une netlist dans un format défini par l'utilisateur de même que une liste des composants qui peuvent être rendus utilisables pour fonctionner avec PCB. Actuellement, nous connaissons deux programmes de capture de schémas qui peuvent s'interfacer avec PCB. Ce chapitre montre comment un schéma peut être pris du début à la fin en utilisant un de ces deux outils de capture de schémas et PCB pour le dessin.

9.1 gEDA

Cette section montre comment utiliser gEDA comme unterface de capture de schémas pour la conception de PCB. Cette section n'est pas destinée à être une documentation complète de gEDA et il est supposé que l'utilisateur est au moins familier avec la suite de programmes de gEDA.

Les étapes de base dans le flux de conception de gEDA + PCB sont:

1. Configurer les répertoires de projets
2. Configurer les fichiers de configuration de gEDA (gschem/gnetlist)
3. Configurer les fichiers de configuration de gsch2pcb
4. Capture de schémas en utilisant `gschem` (partie de gEDA)
5. Créer toutes les empreintes PCB uniques nécessaires pour la conception
6. Générer le dessin initial de PCB en utilisant `gsch2pcb` (partie de gEDA)
7. Disposition de la carte en utilisant `pcb`
8. Effectuer tous les changements de schémas additionnels avec `gschem` et les annotations directes vers PCB avec `gsch2pcb`
9. Générer les fichiers photoplot (RS-274-X, aussi connu comme "Gerber") pour la board vendor

9.1.1 Configurer les Répertoires de Projets

Bien qu'il ne soit pas nécessaire, un répertoire de projet typique contiendra les schémas et les cartes dans le répertoire principal. Les symboles de schémas et les empreintes de circuits qui sont uniques à ce projet sont stockés dans dans les sous-répertoires. Pour cet exemple, 'sym' contient les symboles de schéma spécifiques au projet et 'pkg' contient les empreintes spécifiques du projet. Configurez le répertoire du projet et ses sous-répertoires en exécutant:

```
mkdir ~/myproj
cd ~/myproj
mkdir sym
mkdir pkg
mkdir pkg/newlib
mkdir pkg/m4
```

9.1.2 Configurer les fichiers de configuration de gEDA

Les outils de gEDA, spécifiquement `gschem` et `gnetlist`, utilisent les fichiers de configuration pour initialiser le chemin de recherche pour les bibliothèques de symboles en plus des autres préférences utilisateur. Créer un fichier appelé `gschemrc` dans le répertoire maître du projet. Ajoutez les lignes suivantes à ce fichier:

```
;; list libraries here.  Order matters as it sets the
;; search order
(component-library "./sym")
```

Cela configure le chemin de recherche pour le programme de capture de schémas `gschem`. Maintenant, le netlister, `gnetlist`, doit aussi être configuré. Cela peut être fait en copiant le fichier `gschemrc` dans `gnetlistrc` en lançant `cp gschemrc gnetlistrc`. Alternativement, vous pouvez créer un lien logiciel pour que seul un fichier unique ait besoin d'être mis à jour si des chemins de symboles additionnels sont ajoutés. Le lien est créé en lançant `ln -s gschemrc gnetlistrc`.

9.1.3 Configurer les fichiers de configuration de gsch2pcb

Le programme `gsch2pcb`, qui ne doit pas être confondu avec l'ancien script `gschem2pcb`, est utilisé pour lier le schéma au circuit. `gsch2pcb` est responsable de la création de la netlist utilisée pour fournir des informations de connectivité à PCB de même que pour créer un circuit initial avec tous les composants placés sur le dessin. Les changements de l'annotation directe du schéma sont aussi faits par `gsch2pcb` sur le circuit. `gsch2pcb` utilise un fichier projet pour configurer les noms de fichiers de schéma, les emplacement des bibliothèques de PCB et les noms de fichiers de sortie. Pour créer un fichier projet appelé `project` en utilisant ce qui suit comme un exemple:

```
# List all the schematics to be netlisted
# and laid out on the pc board.
schematics      first.sch second.sch third.sch

# For an output-name of foo, gsch2pcb generates files
# foo.net, foo.pcb, and foo.new.pcb.  If there is no
# output-name specified, the file names are derived from
# the first listed schematic, i.e. first.net, etc.
output-name     preamp
```

9.1.4 Capture de schémas en utilisant gschem

Cette section est assez brève et suppose que vous êtes familiers avec l'utilisation de `gschem` le programme de capture de schémas. Lorsque vous créez vos schémas, assurez-vous d'observer les règles suivantes:

- Assurez-vous que chaque composant dans le schéma possède un attribut `footprint` qui correspond à une empreinte dans la bibliothèque PCB ou une empreinte que vous avez prévu de créer.

- Assurez-vous que toutes les désignations de références sont uniques. Une manière s'en assurer est de lancer le script `refdes_renum` (faisant partie de gEDA) après que le schéma soit créé.

9.1.5 Créer toutes les empreintes de PCB uniques

La création de nouvelles empreintes peut se faire soit en utilisant le style `m4` ou avec celui du style `newlib` des bibliothèques de PCB. Voyez Chapter 8 [Library Creation], page 64 pour les détails sur ce processus. Les empreintes au style `m4` sont stockées dans le sous-répertoire `'pkg/m4'` et pour les empreintes au style `newlib`, vous pouvez les stocker dans le sous-répertoire `'pkg/newlib'`.

9.1.6 Générer un dessin initial de PCB en utilisant `gsch2pcb`

Le programme `gsch2pcb` connecte le schéma et le circuit. Son opération première est d'appeler `gnetlist` pour générer la netlist des connectivités utilisées par PCB pour vérifier les liaisons et instantier les éléments trouvés dans le schéma dans le nouveau circuit. Par défaut, `gsch2pcb` version 0.9, utilise tout style `m4` trouvé en premier et cherche alors le style `newlib` si aucun composant ancien style n'a été trouvé. En utilisant le drapeau `--use-files` ou `-f` avec `gsch2pcb` la priorité est donnée au composants de style `newlib` même si ceux au style `m4` sont trouvés. Vous pouvez souhaiter le vérifier dans la documentation `gsch2pcb` dans le cas où cela changerait dans le futur. Pour démarrer le schéma, lancez `'gsch2pcb projet'` où `'projet'` est le fichier projet créé plutôt. Ceci créera un nouveau fichier netlist, `'preamp.net'` et un nouveau fichier de circuit `'preamp.pcb'`.

9.1.7 Carte de circuit imprimé

Faites fonctionner PCB sur le nouveau schéma en lançant `'pcb preamp.pcb'`. Chargez le fichier netlist en sélectionnant "load netlist file" depuis le menu "fichier". Dans la boîte de dialogue de sélection de fichier, choisissez `'preamp.net'`. Cela charge les informations de connectivité dans PCB.

En utilisant l'outil de sélection, prenez et déplacez les empreintes diverses avec le bouton milieu de la souris. Une fois que les éléments sont désolidarisés, choisissez "optimize rats-nest" depuis le menu "Connexion". Ce choix de menu affiche et optimise les liaisons. Utilisez les liaisons pour vous aider dans le placement des composants. Vous pouvez souhaiter relancer la commande "optimize rats-nest" après avoir déplacé les composants.

Après avoir terminé le placement, utilisez l'outil ligne pour ajouter des pistes sur la carte. Avec l'ajout des pistes, les liaisons correspondantes disparaîtront.

9.2 Annotation directe des changements de schémas

Si des changements sont effectués sur le schéma après que le circuit ait été démarré, `gsch2pcb` peut être utilisé pour faire l'annotation directe de ces changements vers le circuit. Pour annoter directement les changements de schémas, lancez `'gsch2pcb project'`. Cette commande créera les fichiers `'preamp.new.pcb'`, `'preamp.net'` et modifie le fichier `'preamp.pcb'`. Les modifications à `'preamp.pcb'` incluent les annotations directes des changements de valeurs de composants de schémas, d'ajout de nouveaux composants et enlève tous les composants effacés.

9.2.1 Générer les fichiers Photoplot (RS-274-X)

Après avoir complété le circuit, choisissez "edit layer-groupings" depuis le menu "Configuration". La structure LayerGroups vous permet de spécifier quelles couches apparaissent dans chaque groupe de couches de sortie. Par exemple, dans la structure par défaut, le groupe de couches 1 possède la couche "avant" et "arrière". Le fichier de sortie est nommé '1.gbr' si les noms de fichiers DOS sont utilisés ou 'somename_front.gbr' si les noms de fichiers long utilisés contiendront les couches "avant" et "arrière". Les valeurs par défaut sont suffisantes mais cette structure est encore une référence utile.

Choisissez "print layout..." depuis le menu "Fichier". Dans la boîte de dialogue imprimer le schéma, sélectionnez "Gerber/RS-274X" pour le pilote. Sélectionnez les options "Contour", "Alignement" et "Aide au perçage". Pour obtenir des noms de fichiers compatibles DOS, sélectionnez l'option "DOS (8.3) names", sinon, entrez "preamp" pour le nom de fichier. Pressez "OK".

Les fichiers de sortie suivants doivent avoir été créés dans le répertoire projet. Les noms entre parenthèses correspondent aux noms de fichiers de sortie compatibles DOS.

'preamp_frontsilk.gbr (csilk.gbr)'

Top side silk screen.

'preamp_frontmask.gbr (cmask.gbr)'

Top side soldermask relief.

'preamp_front.gbr (1.gbr)'

Top copper.

'preamp_backmask.gbr (smask.gbr)'

Bottom side soldermask relief.

'preamp_back.gbr (2.gbr)'

Bottom Copper.

'preamp_fab.gbr (fab.gbr)'

Dessin de fabrication. Aussi connu comme le dessin de perçage. Ce dessin est utilisé comme référence par le fabricant de cartes mais n'est pas utilisé directement utilisé dans le processus de fabrication.

'preamp_plated-drill.cnc (pdrill.cnc)'

NC Drill format file for the plated through holes.

'preamp_unplated-drill.cnc (udrill.cnc)'

NC Drill format file for the unplated through holes.

'preamp_bom.txt (bom.txt)'

Liste des composants pour la carte.

'preamp_xy.txt (xy.txt)'

Données de centrage (X-Y) pour piloter les machines d'insertion automatique.

9.3 xcircuit

If anyone cares to contribute this section, it will get added. Please submit changes to the bug tracking system at the sourceforge project page for PCB which can be found from the PCB homepage at <http://pcb.sourceforge.net>.

Appendix A Installation and Troubleshooting

Compiling and installing the package should be straightforward. If any problems occur, please contact the author `Thomas.Nau@rz.uni-ulm.de`, or the current maintainer `haceaton@aplcomm.jhuapl.edu` to find a solution and include it into the next release.

A.1 Compiling and Installing

This section covers the steps which are necessary to compile the package.

A.1.1 Quick Start

Starting with version 2.0, `Pcb` has switched to a GNU `autoconf/automake` build system. Installation of `Pcb` consists of three steps: configuration, building, and installing. In a typical installation, these steps are as simple as

```
./configure
make
make install
```

A.1.2 Running the configure Script

The `configure` script accepts all of the standard GNU configure options. For a complete list of configuration options, run `./configure --help`.

‘`INFOLIBDIR`’

must be set to the directory where your GNU info files are located.

‘`PCBLIBDIR`’

is the path of a directory where the font files will be installed.

‘`DEFAULTFONT`’

the name of the default font file.

‘`DEFAULTLIBRARY`’

the name of the default library.

‘`GNUM4`’

the name of GNU's m4 version.

‘`BTNMOD`’

If your window manager has already bound `Mod1` together with some function keys you may want to change this setting. This is true for HP-VUE.

If you find things which must be changed to compile on your system, please add the appropriate `autoconf` tests (if you are familiar with that) and mail a copy to the maintainer, Harry Eaton, at `haceaton@aplcomm.jhuapl.edu`.

If you do not have the appropriate permissions you should run ‘`./pcbtest.sh`’ in the ‘`src`’ directory to run `Pcb` from the installation directory.

A.2 Troubleshooting

There are some known problems. Most of them are related to missing parts of a standard X11 distribution. Some others are caused by third party applications such as X servers. To make this list more complete please mail your problems and, if available, solutions to the

author. The mail address may be found at the beginning of this chapter. In any case, read Section A.2.8 [X11], page 78.

By the way, you **MUST HAVE AN ANSI COMPILER** to make `Pcb` work.

Another source of problems are older versions of `flex` and `bison`. `Pcb` definitely works with `flex-2.4.7` and `bison-1.22` or later. The problems will result in a *syntax error* while parsing files. This should only be a problem if you have modified the `flex` or `bison` input files.

The following list gives you just an idea because I'm not able to test all `Pcb` releases on all platforms.

A.2.1 HP Series 700 and 800

You have to install several `X11` include files or, better, install a complete `X11R5` release. Hewlett-Packard doesn't support the Athena Widgets. So the header files and libraries are missing from the application media, but they are available as a patch. They also do not ship the `ANSI` compiler with the normal operating system release so you have to buy one or use `GCC`. Some of the tools are available as patches.

In addition, `Pcb` has been successfully tested on these platforms with `HPUX 9.*`, `10.*` running self-compiled `X11R5`.

A.2.2 Sun SPARC architecture

There are no known problems with Sun machines if they use `X11R5` instead of `OpenWindows`. `Pcb` compiled successfully with all kinds of `SPARCstations Solaris-2`. [345].

For problems with `OpenWindows` refer to Section A.2.8 [X11], page 78.

A.2.3 Silicon Graphics

`Pcb` has been tested on some boxes running either `IRIX-4.0.5` or `IRIX-5.3`. The former one uses a `X11R4` server. There are no problems. For known problems with `X11R4`, see Section A.2.8 [X11], page 78.

A.2.4 DEC Alpha

`Pcb` compiled and runs without problems on `DEC UNIX V3.2c`.

A.2.5 SCO Unix

John DuBois <spcecdt@deptht.armory.com> wrote:

```
SCO-ODT-3.0 requires the latest version of t1s003, the Athena
widget library (available from sosco.sco.com). The main problems
I have encountered are it core dumps fairly often, especially
while loading/dropping elements...
```

I'll see what I am able to do as soon as I have access to an `SCO` system.

A.2.6 Linux

Since the `X11` version of `Pcb` has been developed on a `Linux` system here are no known problems.

A.2.7 FreeBSD and NetBSD

`Pcb` has been tested on NetBSD and works without any problems. You may also be able to find a NetBSD package at <ftp://ftp.netbsd.org/pub/NetBSD/packages/cad/pcb/README.html> or a FreeBSD port at <http://www.freebsd.org/cgi/url.cgi?ports/cad/pcb/pkg-descr>.

A.2.8 Problems related to X11

There are a some problems related to X11R4 or systems derived from X11 such as OpenWindows. See Section A.2.2 [Sun], page 77. You at least have to change all occurrences of *baseTranslations* in the resource files to *translations* if you are using a X11R4 server. Look at the X11R5 *Intrinsics* manual for details.

The panner widget (print dialog box) appears only in release X11R5 and later. It really simplifies adjusting the offsets. With earlier releases the printout will always appear in the center of the page.

You may have some problems in a mixed X11-OpenWindows environment.

`Pcb` has been tested successfully with X11R6 under Linux 1.1.59 and later.

A.2.9 Problems related to TeX

If your TeX installation complains about a missing `'texinfo.tex'` file copy the one included in this release (directory `'doc'` to your TeX macro directory. Note, there are probably newer versions of this file available from some FTP sites. TeX-3.0 failed, TeX-3.14 worked just fine. Check our FTP server <ftp.uni-ulm.de> for ready-to-print versions of the manuals.

Appendix B Customizing the Menu

The menu system is driven off a data file that contains *resources*. A resource is a hierarchical description of a data tree which, in this case, is mapped to the hierarchical menus used by Pcb.

B.1 Resource Syntax

A resource file is a simple text file. It contains curly braces to group things, spaces between things, and double quotes when strings need to include spaces. There are four fundamental ways of adding data to a resource.

First, a string (either a single word or a quoted string with spaces, we call both “strings” in this appendix) can be added all by itself, to add a string resource to the current resource. This is used, for example, to define the string printed on a menu button. In this example, four strings are added to the *File* resource:

```
File = {
  Sample
  "longer sample"
  some text
}
```

Second, a named string may be added by giving two strings separated by an equals sign. This is used to specify X resources and a few other optional parameters of menus, for example. Note that a string all by itself is thus an “unnamed” string.

```
{"Layer groups" foreground=red sensitive=false}
```

Third, an unnamed subresource may be added. This is used to create submenus and menu buttons. To add a subresource, simply group other things in curly braces. This example describes a resource containing one string and three subresources:

```
{File
  {New do_new()}
  {Save do_save()}
  {Quit do_quit()}
}
```

Lastly, a named subresource may be added by prefixing an unnamed subresource with a string and an equals sign, just as when naming strings. This syntax is used to name the resources used for the main menu and popup menus:

```
MainMenu = {
  ...
}
```

Additionally, the menu parser allows for “hooks” whereby portions of the menu system can be programmatically created at runtime by the application. These hooks are invoked by a single word preceded by an at sign, such as this example where most of the Sizes menu is created automatically:

```
{Sizes
  @sizes
  {"Adjust active sizes ..." AdjustStyle(0)}
```

```
    }
```

In addition to all that, any unquoted pound sign (#) begins a comment. Commented text continues until the end of the containing line. Comments may begin at the beginning of a line, or after other text on the line:

```
# This is a comment
MainMenu = { # This is also a comment
```

B.2 Menu Definitions

To best understand this section, you should find the ‘pcb-menu.res’ file that your Pcb uses and refer to it for examples (see Section B.3 [Menu Files and Defaults], page 81).

A resource defines a menu when it meets certain semantic requirements. The menu hierarchy is reflected as a hierarchy of unnamed subresources, with the first string of each subresource defining the label used for the menu button. A subresource that itself contains subresources becomes a submenu, a subresource that does not becomes a button.

A submenu should only contain subresources for the buttons or submenus within that submenu. Two exceptions are allowed: an initial string sets the label, and the string “-” (a single dash) will create a separator.

A button should not contain subresources, but will contain many strings, named and unnamed. The first member shall be an unnamed string which is the label for the button. Any other unnamed strings within the button’s resource will be used as actions (much like the .Xdefaults action strings), which are functions that will be called when the button is pressed (or popped up, or created, depending on the action). As a convenience, if a left parenthesis is seen, the current “word” will continue at least until the matching right parenthesis. This allows you to pass strings with spaces as arguments to actions without needing to quote the action.

Named resources in button resources will be used as X resources. Such resources can be used to set the font, color, and spacing of buttons. As a convenience, “fg” can be used as an abbreviation for “foreground”.

Within the menu’s resource file, Pcb will look for a few key named subresources. At the moment, the only one it looks for is one called `MainMenu`. This will be used for the main menu bar. In the future, other named subresources will be used for popup resources.

Given all this, a small sample ‘pcb-menu.res’ would be:

```
MainMenu = {
  {File
    {"Load layout" Load(Layout)}
    -
    {"Quit Program" Quit() fg=red font=10x20}
  }
}
```

Within the Pcb sources are specially crafted comments that mark all the actions, flags, menu hooks, and whatnot that Pcb offers. Read the file ‘src/gather-actions’ in the Pcb source tree for documentation for these comments.

B.3 Menu Files and Defaults

Pcb will look for a file which defines its menus, trying the following names:

```
./pcb-menu.res  
$HOME/.pcb-menu.res  
$PCBLIBDIR/pcb-menu.res  
<internal>
```

Note that *pcblibdir* defaults to `‘/usr/local/share/pcb’` (hence, `‘/usr/local/share/pcb/pcb-menu.res’`). The `‘<internal>’` entry refers to a menu definition within the Pcb application itself. The master file for all this is the file `‘src/pcb-menu.res’` in the Pcb source tree. This master source is used to create the internal menu definition as well as being installed in `‘$pcblibdir’`.

You can view the internal menu definition (the default) by running `‘pcb’` with the `-dumpmenu` option, like this:

```
pcb -dumpmenu
```

Appendix C Element Search/Regular Expressions

C.1 Element Search/Regular Expressions

Pcb's search is based on POSIX 1003.2 Regular Expressions. Full POSIX Regular Expressions are supported by Pcb if the regex library was available when Pcb was built. It is easier to show by example how to search than explain POSIX 1003.2. The following table shows the most common Regular Expression characters used to find elements in Pcb:

'\'	Indicates next character should not be interpreted literally if it normally is, and should be interpreted literally if it normally isn't.
'*'	Matches 0 or more instances of preceding character.
'+'	Matches 1 or more instances of preceding character.
'?'	Matches 0 or 1 instances of preceding character.
'.'	Matches any single character other than the newline character.

The following examples illustrate how regular expressions are used to specify element names (reference designators) to search for.

```
'Search for "C1":'
  Enter "C1".
```

```
'Search for all elements that start with "C", such as capacitors:'
  Enter "C.*", that is "C-dot-star".
```

```
'Search for all elements that start with "C" and end with "1",'
  such as "C1", or "C51": Enter "C.*1", that is "C-dot-star-1".
```

```
'Search for only R1 or R10, will not match R100:'
  Enter "R10?".
```

```
'Search for all parts starting with "R12" and ending with the number eight, or
  eighty-eight etc:'
  Enter "R128+".
```

```
'Search for all terminal blocks having a one digit designator such as TB1 or
  TB2:'
  "TB.", that is "TB-dot".
```

```
'Search for all terminal blocks having a two digit designator such as TB21 or
  TB15:'
  "TB..", that is "TB-dot-dot".
```

Appendix D Standard Drill Size Tables

D.1 American Standard Wire Size Drills

\$Id: wire_size.tab,v 1.1 2005/01/29 00:59:08 danmc Exp \$

97 .0059 96 .0063 95 .0067 94 .0071 93 .0075 92 .0079 91 .0083 90 .0087 89 .0091 88 .0095
 87 .0100 86 .0105 85 .0110 84 .0115 83 .0120 82 .0125 81 .0130 80 .0135 79 .0145 78 .0160
 77 .0180 76 .0200 75 .0210 74 .0225 73 .0240 72 .0250 71 .0260 70 .0280 69 .0292 68 .0310
 67 .0320 66 .0330 65 .0350 64 .0360 63 .0370 62 .0380 61 .0390 60 .0400 59 .0410 58 .0420
 57 .0430 56 .0465 55 .0520 54 .0550 53 .0595 52 .0635 51 .0670 50 .0700 49 .0730 48 .0760
 47 .0785 46 .0810 45 .0820 44 .0860 43 .0890 42 .0935 41 .0960 40 .0980 39 .0995 38 .1015
 37 .1040 36 .1065 35 .1100 34 .1110 33 .1130 32 .1160 31 .1200 30 .1285 29 .1360 28 .1405
 27 .1440 26 .1470 25 .1495 24 .1520 23 .1540 22 .1570 21 .1590 20 .1610 19 .1660 18 .1695
 17 .1730 16 .1770 15 .1800 14 .1820 13 .1850 12 .1890 11 .1910 10 .1935 9 .1960 8 .1990 7
 .2010 6 .2040 5 .2055 4 .2090 3 .2130 2 .2210 1 .2280

D.2 American Standard Letter Size Drills

\$Id: letter_size.tab,v 1.1 2005/01/29 00:59:08 danmc Exp \$

A .2340 B .2380 C .2420 D .2460 E .2500 F .2570 G .2610 H .2660 I .2720 J .2770 K
 .2810 L .2900 M .2950 N .3020 O .3160 P .3230 Q .3320 R .3390 S .3480 T .3580 U .3680 V
 .3770 W .3860 X .3970 Y .4040 Z .4130

D.3 Fractional Inch Size Drills

\$Id: fractional_size.tab,v 1.1 2005/01/29 00:59:08 danmc Exp \$

1/64 .0156 1/32 .0313 3/64 .0469 1/16 .0625 5/64 .0781 3/32 .0938 7/64 .1094 1/8 .1250
 9/64 .1406 5/32 .1562 11/64 .1719 3/16 .1875 13/64 .2031 7/32 .2188 15/64 .2344 1/4 .2500
 17/64 .2656 9/32 .2812 19/64 .2969 5/16 .3125 21/64 .3281 11/32 .3438 23/64 .3594 3/8
 .3750 25/64 .3906 13/32 .4062 27/64 .4219 7/16 .4375 29/64 .4531 15/32 .4688 31/64 .4844
 1/2 .5000 33/64 .5156 17/32 .5313 35/64 .5469 9/16 .5625 37/64 .5781 19/32 .5938 39/64
 .6094 5/8 .6250 41/64 .6406 21/32 .6562 43/64 .6719 11/16 .6875 45/64 .7031 23/32 .7188
 47/64 .7344 3/4 .7500 49/64 .7656 25/32 .7812 51/64 .7969 13/16 .8125 53/64 .8281 27/32
 .8438 55/64 .8594 7/8 .8750 57/64 .8906 29/32 .9062 59/64 .9219 15/16 .9375 61/64 .9531
 31/32 .9688 63/64 .9844 1 1.0000

D.4 Metric Drills

\$Id: metric_size.tab,v 1.1 2005/01/29 00:59:08 danmc Exp \$

0.20_mm .00787 0.25_mm .00984 0.30_mm .0118 0.35_mm .0138 0.40_mm .0158
 0.45_mm .0177 0.50_mm .0197 0.55_mm .0217 0.60_mm .0236 0.65_mm .0256 0.70_mm
 .0276 0.75_mm .0295 0.80_mm .0315 0.85_mm .0335 0.90_mm .0354 0.95_mm .0374
 1.00_mm .0394 1.05_mm .0413 1.10_mm .0433 1.15_mm .0453 1.20_mm .0472 1.25_mm
 .0492 1.30_mm .0512 1.35_mm .0531 1.40_mm .0551 1.45_mm .0571 1.50_mm .0591
 1.55_mm .0610 1.60_mm .0630 1.65_mm .0650 1.70_mm .0669 1.75_mm .0689 1.80_mm
 .0709 1.85_mm .0728 1.90_mm .0748 1.95_mm .0768 2.00_mm .0787 2.05_mm .0807
 2.10_mm .0827 2.15_mm .0846 2.20_mm .0866 2.25_mm .0886 2.30_mm .0906 2.35_mm

Index of Resources

A

absoluteGrid 39
 alignmentDistance 39
 allDirectionLines 36, 39

B

backgroundImage 36, 39
 backupInterval 36, 39
 bloat 39
 BTNMOD 76

C

charactersPerLine 36, 39
 connectedColor 40
 cross hairColor 40

D

default font 36
 DEFAULTFONT 76
 DEFAULTLIBRARY 76

E

Element Search 81
 elementColor 40
 elementCommand 36, 40, 56
 elementContentsCommand 42
 elementPath 40
 elementSelectedColor 40

F

fileCommand 36, 40, 56
 filePath 40
 fontCommand 36, 41, 56
 fontFile 36, 41
 fontPath 41

G

GNUM4 76
 grid 41
 gridColor 41

I

INFOLIBDIR 76
 invisibleObjectsColor 41

L

layerColor 41
 layerGroups 36, 41
 layerName 41
 layerSelectedColor 41
 libraryCommand 37, 41, 56
 libraryContentsCommand 37, 56
 libraryFilename 37, 42
 libraryPath 37, 42
 lineThickness 42

M

Measuring distances 32
 media 42

O

offLimitColor 42

P

PCBLIBDIR 76
 pinColor 42
 pinoutFont0..6 42
 pinoutNameLength 37, 42
 pinoutOffsetX 43
 pinoutOffsetY 43
 pinoutTextOffsetX 43
 pinoutTextOffsetY 43
 pinoutZoom 37, 43
 pinSelectedColor 42
 printCommand 43

R

raiseLogWindow 43
 ratCommand 43
 ratPath 43
 Regular Expressions 81
 resetAfterElement 37, 43
 ringBellWhenFinished 37, 43
 routeStyle 37, 43
 rubberBandMode 43

S

saveCommand 37, 44, 56
 saveInTMP 37, 44
 saveLastCommand 37, 44
 scriptFilename 38
 Searching for elements 31
 shrink 44
 size 38, 44

stipplePolygons 44

T

textScale 44

U

useLogWindow 44

V

viaColor 44

viaDrillingHole 44

viaSelectedColor 44

viaThickness 44

volume 38, 45

W

warnColor 45

Z

zoom 45

Index of Actions, Commands and Options

+		A	
+alldirections	36	AddRats()	45
+reset	37	ApplyVendor()	46
+ring	37	Atomic()	46
+s	37	B	
+save	37	Bell()	46
-		C	
--copyright	38	ChangeClearSize()	46
-alldirections	36	ChangeDrillSize()	46
-background	36	ChangeFlag()	47
-backup	36	ChangeHole()	47
-c	36	ChangeName()	47
-copyright	38	ChangeOctagon()	47
-fontfile	36	ChangeSize()	47
-help	38	ChangeSquare()	47
-lelement	36	ClrFlag()	48
-lfile	36	Command()	48
-lfont	36	Connection()	48
-lg	36	D	
-libname	37	DeleteRats()	48
-libpath	37	DisableVendor()	48
-llib	37	DisperseElements()	48
-llibcont	37	Display()	48
-loggeometry	37	DRC()	49
-pnl	37	E	
-pz	37	EditLayerGroups()	49
-reset	37	EnableVendor()	49
-ring	37	ExecuteFile()	49
-rs	37	L	
-s	37	Load()	49
-save	37	LoadVendor()	49
-script	38	M	
-sfile	37	MarkCrosshair()	50
-size	38	Mode()	50
-v	38	MovePointer()	51
-version	38	MoveToCurrentLayer()	51
:		N	
:actionCommand()	34	New()	51
:l	34		
:le	34		
:m	34		
:q	34		
:rn	34		
:s	34		
:w[q]	34		

P

PasteBuffer()	51
Polygon()	52
Print()	52

Q

Quit()	52
--------	----

R

Redo()	52
RemoveSelected()	53
Report()	53
RouteStyle()	53

S

Save()	53
Select()	53
SetFlag()	53
SetValue()	53
SwapSides()	54
SwitchDrawingLayer()	54

T

ToggleHideName()	54
ToggleVendor()	54
ToggleVisibility()	54

U

Undo()	54
UnloadVendor()	55
Unselect()	55

Index of Concepts

- /
- /tmp..... 26, 37, 44
- A**
- action command..... 34
- actions..... 45
- actions file, executing..... 49
- Actions, initiating..... 34
- affichage des informatios de statut..... 15
- affichage des noms d'éléments..... 13
- alignment..... 39
- alignment targets..... 27
- Alpha..... 77
- ancienne biblioth[^]c[^]3[^]a8que..... 7
- arc..... 9
- arc, an example..... 22
- architecture..... 77
- arrow tool..... 28
- ASCII files, format of..... 55
- atomic..... 46
- auto-routeur..... 14
- B**
- background..... 36, 39
- backup..... 26, 36, 37, 39, 44
- basic types..... 56
- bell..... 46
- bloat..... 39
- buffer, an example..... 25
- buffer, convert contents to element..... 24
- buffer, selecting a..... 51
- button translations..... 45
- C**
- capture de schéma..... 71
- cat..... 40, 41, 44
- centering..... 48
- champ d'entr[^]c[^]a9e, position du..... 15
- change active layer..... 17
- change drawing layer..... 54
- change object name..... 47
- change settings..... 53
- change sizes..... 46, 47
- change square flag..... 47
- change viewing side..... 54
- characters per line..... 36, 39
- clearance..... 9
- clearance, changing of objects..... 46
- clipping lines to 45 degree..... 39, 48
- clipping of lines..... 36
- closing a polygon..... 52
- color printout..... 27
- color, warning..... 45
- colors..... 40, 41, 42, 44, 45
- command-line options..... 35
- comment commencer..... 11
- compile, how to..... 76
- Configuration, menu déroulant..... 13
- configure..... 76
- connection, removing an..... 55
- connections, colors..... 40
- connections, creating list of..... 28
- connections, resetting..... 48
- connections, resetting after element..... 37, 43
- connections, searching for..... 48
- Connexion, menu déroulant..... 14
- contrôleur de règles de dessin, invocation..... 14
- copy an object..... 55
- copying objects..... 51
- copying, an example..... 26
- copyright..... 38
- creating objects..... 21
- cursor color..... 40
- cursor movements..... 51
- cursor position..... 50
- cursor steps..... 41
- cutting objects..... 51
- D**
- DEC..... 77
- défaire..... 13
- default font..... 36, 41
- default layout size..... 44
- default library..... 42
- default text scaling..... 44
- default translations..... 55
- dégagement, pour les nouvelles lignes..... 13
- design rule checking..... 30, 49
- device, selecting an output..... 26
- directory /tmp..... 26, 37, 44
- dispersing elements..... 48
- display..... 44
- displaying element names..... 48
- displaying pinout..... 48
- distributing elements..... 48
- DOS filenames..... 27
- drawing objects..... 21
- drc..... 30, 39, 44, 49
- drill..... 53
- drill sizes, list of standard..... 82
- Drill table..... 32
- drilling hole, changing of objects..... 46
- drilling hole, setting of initial size..... 53

E

Écran, menu déroulant	13
Édition, menu déroulant	13
element name, hiding	54
element name, removing from silk-screen	54
Element Search	81
élément, affichage des noms	13
element, an example	24
element, color	40, 41
element, command	36, 40
element, creating a new package	24
element, display names of	48
élément, édition	14
element, file format	59
element, files	36, 40
element, loading to buffer	34
element, move name of	55
élément, un survol	5
elements, dispersing	48
elements, distributing	48
entering user commands	33
erasing objects	21
exactitude de la biblioth�c�a8que	7
example files	24
example of buffer handling	25
example of connection lists	28
example of copying	26
example of creating an element	24
example of element handling	24
example of line handling	22
example of loading	26
example of loading an element file	24
example of moving	26
example of pastebuffer handling	25
example of pin handling	24
example of polygon handling	22
example of printing	26
example of rectangle handling	22
example of saving	26
example of text handling	23
example of via handling	23
exit	34, 52

F

Fen�tre, menu déroulant	15
Fichier, menu déroulant	13
file format, element data	59
file format, font data	61
file format, layout data	57
file format, libraries	62
file format, library contents	61
file formats	55
file formats, basic types	56
file load command	36, 40
file save command	37, 44
flags, changing	47
flags, clearing	48

flags, setting	53
font command	36, 41
font file, format of	61
font files	36, 41
font, used for pin names	42
format of element files	59
format of font files	61
format of layout files	57
format of libraries	62
format of library contents	61
FreeBSD	77

G

gEDA, comment l'interfacier	72
GNU build system	76
GNU configure script	76
grid	19, 39, 41
grid color	41
grid, absolute and relative	48
grid, display	48
grid, setting of	53
grille, affichage	13
grille, alignement	13
groups	36, 41
groups, editing of	49
gschem, comment l'interfacier	72

H

Hewlett Packard	77
hide element name	54
HP	77

I

Info, menu déroulant	15
information about objects	53
information de statut	15
inputfield, saving entered command-line	37, 44
inputfield, start user input	48
install, how to	76
interface de sch�ma	71

K

key translations	45
keyboard bell	37, 43

L

layer controls	17
layer groups	8
layer visibility, toggling	54
layer, change active	54
layer, name of	41
layers, an overview	7
layers, changing which is active	17
layers, colors	41
layers, editing of groups	49
layers, groups	36, 41
layers, switching on/off	17
layout files	36, 37, 40, 44
layout files, format of	57
layout files, saving of	34
layout size	38
layout, default size of	44
layout, loading a	34
layout, loading to buffer	34
layout, merging a	34
layout, printing a	52
layout, start a new	51
layout-name	34
length of a pin name	37, 42
length of outputline	36
library command	37, 41
library contents command	37, 42
library contents file, format of	61
library creation	63
library file, format of	62
library name	37, 42
library search path	37
library searchpath	42
library window	20
line clipping	36
linelength	39
lines, an example	22
lines, an overview	8
lines, clipping to 45 degree	39, 48
lines, setting of initial size	53
lines, size	42
Linux	77
list of connections	39
listing libraries	37
listing library contents	42
loading a layout to buffer	34
loading elements	36, 37, 40, 41
loading elements to buffer	34
loading files	49
loading fonts	36, 41
loading layouts	34, 36, 40
loading symbols	36, 41
loading, an example	26
log window	20, 37, 43, 44

M

m4	40
m4, preprocessing example files	24
mark	50
masque de soudure, visualisation et édition	13
Measuring distances	32
media	42
media margin	42
media, size of	27
menus	12
merging layouts	34
messages	20, 37, 43, 44
mirroring printout	27
mode selection	17
mode, selecting of	50
mounting holes	47
move	43
move an object	55
moving objects	28
moving objects to current layer	51
moving, an example	26

N

name of an element	48
name, change an objects	47
namelength of pins	37, 42
NetBSD	77
netlist	10, 29, 43, 45, 48
Netlist Window	20
netlist, file format	61
netlist, reading	61
nom de couche	5
noms uniques	13

O

object, change name of	47
object, changing the size of an	21
object, copy an	55
object, creating an	21
object, drawing and removing	21
object, move an	55
object, removing an	21, 55
objects, moving to current layer	51
objets du schéma, un survol	4
octagonal flag, changing	47
octagonal flag, clearing	48
octagonal flag, setting	53
octagonal pins and vias	47
off limit color	42
offset of pinnames	43
offset of pinout	43
offset of printout	27
OpenWindows	77
operation modes, selecting of	50
optimizer	31
outline printout	27

output device	26
outputline, length of	36
overlap, minimum	30

P

Panner control	16
pastebuffer, an example	25
pastebuffer, convert contents to element	24
pastebuffer, selecting a	51
path for element files	40
path for font files	41
path for layout files	40
path for libraries	42
PC UNIX	77
PCB, un survol	3
pin color	42
pin, name of	37, 42
pinout, display of	48
pinout, font to display pin names	42
pinout, zoomfactor of display	37, 43
pins, an example	24
pins, changing shape of	47
pointer, moving of	51
polices, un survol	5
polygon	44
polygon point, go back to previous	52
polygon, an example	22
polygon, an overview	9
polygon, closing a	52
popping up menus	12
postprocessing layout data	37, 44
preprocessing element data	36, 37, 40
preprocessing font data	36, 41
preprocessing layout data	36, 40
preventing loss of data	26, 37, 44
print command	27
print media	27, 42
print offset	27
printing	43
printing a layout	52
printing, an example	26
problems	76

Q

quit	34, 52
----------------	--------

R

rapport	15
rapport de perçage	15
rapport objet	15
rat's nest	34
rat-line	29, 45, 48
rats nest	29, 43, 45, 48
rats-nest	10
recover	52, 54

rectangle, an example	22
redo	52
redrawing layout	48
refaire	13
refreshing layout	48
Regular Expressions	81
release, current	38
removing connections	55
removing objects	21, 55
removing selected objects	53
report	53
resetting found connections	37, 43, 48
ressources	39
rotate	43
rotating a buffer	51
rotating printout	26
routing style	37, 43, 53
rubber band	13
rubberband	43, 48

S

saving connections	53
saving files	53
saving found connections	48
saving last entered user command	37, 44
saving layouts	26, 34, 37, 44
saving, an example	26
scaling a printout	27
scanning connections	48
SCO	77
script file, executing	49
scrolling	55
searching connections	48
Searching for elements	31
searchpath for element files	40
searchpath for font files	41
searchpath for layout files	40
searchpath for libraries	42
selected object, removing an	53
selecting a buffer	51
selecting a new tool	17
selecting objects	53
selecting, using the arrow tool	28
selection	53, 55
selection d'objets, changement de tailles	14
selection d'objets, suppression	14
Selection, menu déroulant	14
SGI	77
shrink	44
signal	46
Silicon Graphics	77
size of a layout	38
size of lines	42
size of lines and vias	53
size of vias	44
sizes, changing of objects	46, 47
snap to pins	13

- Solaris 77
spacing, minimum 30
speaker volume 38, 45
square flag, changing 47
square flag, changing of objects 47
square flag, clearing 48
square flag, setting 53
standard drill sizes 82
start user input 48
starting a new layout 51
starting Pcb 35
startup actions script 38
strings, an example 23
strings, an overview 10
Sun 77
symboles, un survol 5
symbols 36, 41
- T**
- Tailles, menu déroulant 13
tampon de copie, menu déroulant 14
Tampon, menu déroulant 14
temporary files 26, 37, 44
TeX, problems 78
text, an example 23
text, an overview 10
text, default scaling 44
thermal flag, changing 47
thermal flag, clearing 48
thermal flag, setting 53
thickness of lines 42
thickness of objects 21
thickness of vias 44
thickness, changing of objects 47
toggle layer visibility 54
tool selection 17
tool, arrow 28
trace optimizer 31
translations 45, 55
troubleshooting 76
two line mode 8
- U**
- undo 54
undo, multi-action resources 46
unix command 36, 37, 40, 41, 42, 44
unselect objects 55
- user commands 33
user input 55
- V**
- vendor drill table 46
Vendor drill table 32
vendor drill table, disabling 48
vendor drill table, enabling 49
vendor drill table, loading 49
vendor drill table, toggling 54
vendor drill table, unloading 55
vendor map 46
vendor map, disabling 48
vendor map, enabling 49
vendor map, loading 49
vendor map, toggling 54
vendor map, unloading 55
Vendor mapping 32
Vendor rules 32
Version Atari 2
version, current 38
vias, an example 23
vias, changing shape of 47
vias, color 44
vias, converting to mounting hole 47
vias, setting of initial size 53
vias, size 44
vias, un survol 5
View, adjusting 16
viewing side, changing of 54
volume of speaker 38, 45
- X**
- X11 38
X11 default translations 55
X11 ressources 39
X11 translations 45
X11, problems 78
xcircuit, how to interface with 75
- Z**
- zoom of Layout area 45
zoom of pinout window 37, 43
zoom, initialisation 13
zoom, setting of 53